ADVANCE STRUCTRAL DESIGN LABORTARY

LAB MANUAL

Academic Year	:	2019 - 2020
Subject Code	:	ACE113
Regulations	:	IARE – R16
Class	:	VII Semester (CE)

PREPARED BY Mr. CH. VENUGOPAL REDDY

ASSISTANT PROFESSOR

Mr. S. SIVA RAMAKRISHNA

ASSISTANT PROFESSOR



DEPARTMENT OF CIVIL ENGINEERING INSTITUTE OF AERONAUTICAL ENGINEERING

(Autonomous) Dundigal – 500 043, Hyderabad



INSTITUTE OF AERONAUTICAL ENGINEERING

(Autonomous)

Dundigal, Hyderabad - 500 043

DEPARTMENT OF CIVIL ENGINEERING

Program: Bachelor of Technology (B. Tech)

VISION OF THE DEPARTMENT

To produce eminent, competitive and dedicated civil engineers by imparting latest technical skills and ethical values to empower the students to play a key role in the planning and execution of infrastructural & developmental activities of the nation.

MISSION OF THE DEPARTMENT

To provide exceptional education in civil engineering through quality teaching, state-of-the-art facilities and dynamic guidance to produce civil engineering graduates, who are professionally excellent to face complex technical challenges with creativity, leadership, ethics and social consciousness.



INSTITUTE OF AERONAUTICAL ENGINEERING

(Autonomous)

Dundigal, Hyderabad - 500 043

DEPARTMENT OF CIVIL ENGINEERING

Program: Bachelor of Technology (B. Tech)

PROGRAM OUTCOMES (PO's)

PO1	Engineering knowledge: Apply the knowledge of mathematics, science,
	engineeringfundamentals, and an engineering specialization to the solution of complex
	engineering problems.
PO2	Problem analysis: Identify, formulate, review research literature, and analyze
	complexengineering problems reaching substantiated conclusions using first principles
	of mathematics, natural sciences, and engineering sciences.
PO3	Design/development of solutions : Design solutions for complex engineering problems
	anddesign system components or processes that meet the specified needs with
	appropriate consideration for the public health and safety, and the cultural, societal, and
	environmental considerations.
PO4	Conduct investigations of complex problems: Use research-based knowledge and
	researchmethods including design of experiments, analysis and interpretation of data,
	and synthesis of the information to provide valid conclusions.
PO5	Modern tool usage: Create, select, and apply appropriate techniques, resources, and
	modernengineering and IT tools including prediction and modeling to complex
	engineering activities with an understanding of the limitations.
PO6	The engineer and society: Apply reasoning informed by the contextual knowledge to
	assesssocietal, health, safety, legal and cultural issues and the consequent responsibilities
	relevant to the professional engineering practice.
PO7	Environment and sustainability: Understand the impact of the professional
	engineering solutionsin societal and environmental contexts, and demonstrate the
	knowledge of, and need for sustainable development.
PO8	Ethics: Apply ethical principles and commit to professional ethics and responsibilities
	and norms of the engineering practice.
L	1

PO9	Individual and team work : Function effectively as an individual, and as a member or
	leader indiverse teams, and in multidisciplinary settings.
PO10	Communication : Communicate effectively on complex engineering activities with the
	engineeringcommunity and with society at large, such as, being able to comprehend and
	write effective reports and design documentation, make effective presentations, and give
	and receive clear instructions.
PO11	Project management and finance: Demonstrate knowledge and understanding of
	theengineering and management principles and apply these to one's own work, as a
	member and leader in a team, to manage projects and in multidisciplinary environments.
PO12	Life-long learning: Recognize the need for, and have the preparation and ability to
	engage inindependent and life-long learning in the broadest context of technological
	change.



INSTITUTE OF AERONAUTICAL ENGINEERING

(Autonomous)

Dundigal, Hyderabad - 500 043

DEPARTMENT OF CIVIL ENGINEERING

Program: Bachelor of Technology (B. Tech)

The Program Specific outcomes (PSO's) listed below were developed specifically to meet the Program Educational Objectives (PEO's). The focus of these PSO's is consistent with the set of required PO's identified in the NBA accreditation guidelines.

The Civil Engineering PSO's require that graduates receiving a Bachelor of Technology in Civil Engineering degree from IARE demonstrate the following.

	PROGRAM SPECIFIC OUTCOMES (PSO's)
PSO1	ENGINEERING KNOWLEDGE: Graduates shall demonstrate sound knowledge in analysis, design, laboratory investigations and construction aspects of civil engineering infrastructure, along with good foundation in mathematics, basic sciences and technical communication
PSO2	BROADNESS AND DIVERSITY: Graduates will have a broad understanding of economical, environmental, societal, health and safety factors involved in infrastructural development, and shall demonstrate ability to function within multidisciplinary teams with competence in modern tool usage.
PSO3	SELF-LEARNING AND SERVICE: Graduates will be motivated for continuous self-learning in engineering practice and/or pursue research in advanced areas of civil engineering in order to offer engineering services to the society, ethically and responsibly.

BUILDING INFORMATION MODELING LAB SYLLABUS

EXP. NO.	NAME OF THE EXPERIMENT
1	Introduction to staad pro
2	Analysis of continuous beam
3	Analysis of single storey frame
4	Analysis of multi-storey frame
5	Design of multi-storey frame
6	Analysis of multi-storeyed building
7	Design of multi-storeyed building
8	Wind load analysis on rcc building
9	Analysis and design of steel truss
10	Analysis and design of isolated footing
11	Analysis and design of combined footing
12	Analysis of bridge deck
13	Revision

ATTAINMENT OF PROGRAM OUTCOMES (PO's) & PROGRAM SPECIFIC OUTCOMES

Exp No.	Name of Experiment	Program Outcomes	Program Specific
		Attained	OutcomesAttained
1.	Introduction to staad pro	PO 1	PSO1
2.	Analysis of continuous beam	PO 1, PO 2, PO 3	PSO1
3.	Analysis of single storey frame	PO 1, PO 2, PO 5	PSO1
4.	Analysis of multi-storey frame	PO 1, PO 3, PO 5	PSO1
5.	Design of multi-storey frame	PO 1, PO 3, PO 5	PSO1
6.	Analysis of multi-storeyed building	PO 1, PO 2, PO 5	PSO1
7.	Design of multi-storeyed building	PO 1, PO 3, PO 5	PSO1
8.	Wind load analysis on rcc building	PO 1, PO 2, PO 3, PO 5	PSO1
9.	Analysis and design of steel truss	PO 1, PO 2, PO 3, PO 5	PSO1
10.	Analysis and design of isolated footing	PO 1, PO 2, PO 3, PO 5	PSO1
11.	Analysis and design of combined footing	PO 1, PO 2, PO 3, PO 5	PSO1
12.	Analysis of bridge deck	PO 1, PO 3, PO 5	PSO1
13.	Revision		

MANDATORYINSTRUCTIONS

- 1. Students should report to the labs concerned as per the timetable.
- 2. Record should be updated from time to time and the previous experiment must be signed by the faculty in charge concerned before attending the lab.
- 3. Students who turn up late to the labs will in no case be permitted to perform the experiment scheduled for the day.
- 4. After completion of the experiment, certification of the staff in-charge concerned in the observation book is necessary.
- 5. Students should bring a notebook of about 100 pages and should enter the readings/observations/results into the notebook while performing the experiment.
- 6. The record of observations along with the detailed experimental procedure of the experiment performed in the immediate previous session should be submitted and certified by the staff member in-charge.
- 7. Not more than FIVE students in a group are permitted to perform the experiment on a set up.
- 8. The group-wise division made in the beginning should be adhered to, and no mix up of student among different groups will be permitted later.
- 9. The components required pertaining to the experiment should be collected from Lab- incharge after duly filling in the requisition form.
- 10. When the experiment is completed, students should disconnect the setup made by them, and should return all the components/instruments taken for the purpose.

- 11. Any damage of the equipment or burnout of components will be viewed seriously either by putting penalty or by dismissing the total group of students from the lab for the semester/year.
- 12. Students should be present in the labs for the total scheduled duration.
- Students are expected to prepare thoroughly to perform the experiment before coming to Laboratory.
- 14. Procedure sheets/data sheets provided to the students groups should be maintained neatly and are to be returned after the experiment.
- 15. DRESS CODE:
- 1. Boys Formal dress with tuck in and shoes.
- 2. Girls Formal dress (salwarkameez).
- 3. Wearing of jeans is strictly prohibited

S. No.		Page No.
1	Vision and Mission of the department	02
2	Program Outcomes (PO's)	03
3	Program Specific Outcomes (PSO's)	05
4	Mandatory Instructions	08
5	Contents	10
6	Experiment No 1:Introduction to staad pro	11
7	Experiment No 2: Analysis of continuous beam	15
8	Experiment No 3: Analysis of single storey frame	22
9	Experiment No 4: Analysis of multi-storey frame	29
10	Experiment No 5: Design of multi-storey frame	33
11	Experiment No 6: Analysis of multi-storeyed building	39
12	Experiment No 7: Design of multi-storeyed building	42
13	Experiment No 8: Wind load analysis on rcc building	44
14	Experiment No 9: Analysis and design of steel truss	47
15	Experiment No 10: Analysis and design of isolated	62
	footing	02
16	Experiment No 11: Analysis and design of combined	67
	footing	
17	Experiment No 12: Analysis of bridge deck	70
18	Experiment No 13: Revision	

CONTENTS

EXPERIMENT NO. 1

INTRODUCTION ON STAAD PRO

Aim: To study the introduction about STAAD Pro

Overview:STAAD- Standard Analyze and Design

Company name – Bentley

Version- STAADV8i.

STAAD or (STAAD Pro) is a structural analysis and design computer program originally developed by Research Engineers International in Yorba Linda, CA. In late 2005, Research Engineer International was bought by Bentley Systems. An older version called STAAD-III for windows is used by Iowa State University for educational purposes for civil and structural engineers. The commercial version STAAD Pro is one of the most widely used structural analysis and design software. It supports several steel, concrete and timber design codes. It can make use of various forms of analysis from the traditional 1st order static analysis, 2nd order p-delta analysis, geometric nonlinear analysis or a buckling analysis. It can also make use of various forms of dynamic analysis from modal extraction to time history and response spectrum analysis.

In recent years it has become part of integrated structural analysis and design solutions mainly using an exposed API called Open STAAD to access and drive the program using a VB macro system included in the application or other by including open STAADfunctionality in applications that themselves include suitable programmable macro systems. Additionally STAAD Pro has added direct links to applications such as RAM Connection and STAAD Foundation to provide engineers working with those applications which handle design post processing not handled by STAAD Pro itself.

Advantages:

- 1. Easy to use interface,
- 2 Conformation with the Indian Standard Codes
- 3. Versatile nature of solving any type of problem
- 4. Accuracy of the solution.

STAAD Pro features a state-of-the-art user interface, visualization tools, powerful analysis and design engines with advanced finite element and dynamic analysis capabilities. From model generation, analysis and design to visualization and result verification, STAAD Pro is the professional's choice for steel, concrete, timber, aluminum and cold-formed steel design of low and high-rise buildings, culverts, petrochemical plants, tunnels, bridges, piles and much more.

STAAD Pro consists of the following:

The STAAD Pro Graphical User Interface:

It is used to generate the model, which can then be analyzed using the STAAD engine. After analysis and design is completed, the GUI can also be used to view the results graphically.

The STAAD analysis and design engine:

It is a general-purpose calculation engine for structural analysis and integrated Steel, Concrete, timber and aluminum design.

To start with we have solved some sample problems using STAAD Pro and checked the accuracy of the results with manual calculations. The results were to satisfaction and were accurate. In the initial phase of our project we have done calculations regarding loadings on buildings and also considered seismic and wind loads.

Structural analysis comprises the set of physical laws and mathematics required to study and predicts the behavior of structures. Structural analysis can be viewed more abstractly as a method to drive the engineering design process or prove the soundness of a design without a dependence on directly testing it.

To perform an accurate analysis a structural engineer must determine such information as structural loads, geometry, support conditions, and materials properties. The results of such an analysis typically include support reactions, stresses and displacements. This information is then compared to criteria that indicate the conditions of failure. Advanced structural analysis may examine dynamic response, stability and non-linear behavior. The aim of design is the achievement of an acceptable probability that structures being designed will perform satisfactorily during their intended life. With an appropriate degree of safety, they should sustain all the loads and deformations of normal construction and use and have adequate durability and adequate resistance to the effects of seismic and wind. Structure and structural elements shall normally be designed by Limit State Method. Account should be taken of accepted theories, experiment and experience and the need to design for durability. Design, including design for durability, construction and use in service should be considered as a whole. The realization of design objectives requires compliance with clearly defined standards for materials, production, workmanship and also maintenance and use of structure in service.

The design of the building is dependent upon the minimum requirements as prescribed in the Indian Standard Codes. The minimum requirements pertaining to the structural safety of buildings are being covered by way of laying down minimum design loads which have to be assumed for dead loads, imposed loads, and other external loads, the structure would be required to bear. Strict conformity to loading standards recommended in this code, it is hoped, will not only ensure the structural safety of the buildings which are being designed.

Structural engineering is the branch of civil engineering that deals with the analysis and Design of structure that will support or resist the stresses, forces and loads. Throughout the history, Civil engineers have made an important contribution to improve the environment by designing and Construction major structures and facilities. The profession requires a lot of accuracy because most ofthetime; the final result of any project will directly or indirectly affect people's lives and safety. As a Result, software usage in this industry reduces the complexity of loss of challenging projects.

STAAD (Structural Analysis and Design Program) is a general structural and design program With applications primarily in the building industry-commercial buildings, bridges and highway Structures, industrial structures, chemical plant structures, dams, retaining walls, turbine foundations, Culverts and other embedded structures [23]. STAAD supports several steel, concrete and timber Design codes. It offers various analysis methods such as the traditional 1st order

static analysis, 2ndOrder P-delta analysis, geometric nonlinear analysis and the buckling analysis. It can also analyze various type of dynamic analysis starts from model extraction to time history and response spectrum analysis. STAAD is fast, efficient, easy to use and accurate platform, conformation with many Standard codes and qualified to solve any type of problem. These features had made the STAAD the Professional's choice. Today, STAAD is one of the most popular structural engineering software Products.

Methods in STAAD Pro:

- Snap and grid method
- Structural wizard
- Excel method
- DXFmethod
- STAAD editor method

Snap and grid method:

Open STAAD Pro> snap node/ beam > edit. Plane X-Y

Angle of plane: Y-Y Grid origin

Х	Y	Z
0	0	0

In this you can change the values and spacing of the coordinates. Snap and grid method>snap node beam> to create.

Structural wizard:

Geometry>run structural wizard>model type(frame model)> bay frame> transfer> yes> close.

Excel sheet method:

To create node and member

DXF method:

To import the file from AutoCAD format to STAAD format

a) Draw in AutoCAD> save> file type: AutoCAD 2007/ LT 2007 DXF*(dxf)> save> close.

b) Open STAAD Pro> file> import> select required file> ok.

Result:

Pre-Viva Questions:

- 1. Explain the use of AutoCAD in staad.pro
- 2. Explain the difference between global and local axis
- 3. Explain different types of loads that acts on structure
- 4. Explain different types of supports
- 5. What is code book for RCC design?

Post Viva Questions:

- 1. Define Staad.Pro
- 2. What is difference between AutoCAD and Staad.Pro?
- 3. Explain the abbreviation for Staad.pro
- 4. How to select nodes in staad.pro
- 5. How to select beams in staad.pro

EXPERIMENT NO. 2

ANALYSIS OF CONTINUOUS BEAM

Aim: To analyze the continuous beam using staad.pro

Software:STAAD Pro.

Procedure:

Following are the step wise procedures for Staad Pro Problems (CONTINUOUS BEAM)

- 1. Double click the Staad Pro Icon on Desk top
- 2. Select Plane , Meter, Kilo Newton and write File Name & click Next

Ž Ⅲ File Help	STAAD.Pro V	8i (SELECTseries 5)	- 0 ×
STAAD.Pro V8 i			Bentley Settelelay Infrastructure
Project Tasks Recent Files		New	
B. New Project Image: Comp Project Vise Open Project Vise Eartype Manager Backup Manager Backup Manager	Space Pare Pare Trues	File Name: CONTINUOUS BEAM Lookino: C \SPhvVB SS9.STAAD/Plugm\	
License managemen	A PLANE structure is bound by a global 2 plane.	CY coordinate system with loads in the same	
License Configuration ✓ Advanced Analysis Trajes ✓ STAAD beens (Bridge Codes) ✓ STAAD beens (Bridge Codes) ✓ Codes ✓ STAAD beens (Bridge Codes) ✓ Codes ✓ STAAD beens (Bridge Codes)	Length Units Orich Decimeter Foot ® Meter Milmeter Kilometer Certimeter	Fore Units Proved Otention O'ReForm O'Decaffereton O'Roparn @ Richeston O'Metro Ton O'Megafiereton	
STAAD Nows This channel news is not available	< Back	Net > Cancel Heb	
	🖬 🧕	NAR GRADING	- 🏭 🏞 🕯 🚓 ENG 01:58 PM 30-07-2015

3. Add beam, Finish

Ž Ⅲ File Help	STAAD.Pro V8i (SELECTseries 5)	- 0 ×
Tre 1460 STAAD.ProV82 Status Project lass Oren Data Oren Dat	STADDho VBI (SELECTuries 5)	
Itemes Configuration Image: Configuratio		
		- ■ III III ■ ENG 01:39 PM 30-07-2015

4. Click on XY plane and cut Screen (Snap node/beam) screen by clicking at right top corner.

5. Enter Coordinates of each joint of above beam

File Ext View Tool Select Generativ Commands Analyze Model Window Help Go C C C C C C C C C C C C C C C C C C C	and a second	- 8	й	STAAD.Pro V8i (SELECTseries 5) - CONTINUOUS BEA	Ĩ
이 관 에 나 비 가 지 수 다 가 나 나 나 나 가 나 가 나 다 나 나 나 나 나 나 가 가 가 가				s Analyze Mode Window Help	File Edit View Tools
CONTINUOUS BEAM - Whole Structure			Passe Ina Feit	≝↗│] 🖆 😅 🖬 🖬 🖓 X
Image: Solution of the state of the stat			P	< Ⅲ Q & Q Q Q Q @ # Q Q <	688888
Image: State Postprocessing Read Design Foundation Design FAM Cannection Relige Design Piging Earthquebe Image: State Design CONTINUOUS BEAM - Whole Structure Image: State Design Image: State Design <td></td> <td></td> <td>*</td> <td>A 1947年の大学の1948 1981 1981 1981 1981 1981 1981 1981</td> <td>/ 5 日 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1</td>			*	A 1947年の大学の1948 1981 1981 1981 1981 1981 1981 1981	/ 5 日 6 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Image: Processing Meet Design Concrete Design Longer Concrete Design Co					E 24
CONTINUOUS BEAM - Whole Structure CONTINUOUS BEAM - Whole Structure 0 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000			at Design pinters Front motor	and partial particles partial part cannot all partice particles at an	Atadalian Doub
CONTINUOUS BEAM - Whole Structure CONTINUOUS BEAM - () I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I I			an Design Piping Farinquake	oncrete Design Poundation Design IVOP Connection Bridge Deck Advanced -	Ro Prodeing Loss
Image: Constraint of the state of	3	CONTINUOUS BEAM		CONTINUOUS BEAM - Whole Structure	14 B B
		Node X T Z m m m			N 1 1
		1 0.000 0.000 0.000			128 1 2
		3 11.000 0.000 0.000			
(本)		4 16.000 0.000 0.000			A 8 -
					TAL MA SS
					S = 44
					Par 55
					1 🐣 B
			1		- 12
CONTINUOUS BEAM	3	CONTINUOUS BEAM 📼 💷 😂			2 8
A Beam Node A Node B Property Ref	T.	Beam Node A Node B Property Refn.	•		An 8 8
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	+	1			Tara D. A
					- I de
					- m
					16
					E FI.
	>	< .			No 1
anti i i i i i i i i i i i i i i i i i i	N-m	a Ma Input Units: KN	Modeling		Release on node at other er
	и	02:05 PM			

Cut 'Node Screen ', Cut 'Structure screen ', Expand working screen

- 1 000
- 2 600
- 3 1100
- 4 1600
- 6. Connect all joints by beam element , join nodes by nodesindividually

Now the screen should appear like a 3 span beam with nodes clearly seen at the end of each span This step is very important.



7. Now select Commands. Under this select Member Property\Prismatic and click Rectangle.

Enter following details YD = 0.45

ZD= 0.30

8. Now repeat above steps and assign Pin support to remaining two central supports.



9. Select Commands\Loading\Primary Load

Surface Thickness Member Property	, RQEEQO	N 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	
Material Constants Geometric Constants	• 9 1 9 2 1 1 1 1	\$ 8	
Support Specifications	Design RAM Connection Bridge Deck Ad	Ivanced Slab Design Piping Earthqu	ake
Member Specifications Plate Element Specifications	AM - Whole Structure	- 0 💌	Load & Definition
Master/Slave Specification	•		Load Cases Details
Pre Analysis Print	•		Load Envelopes
Not Define Damping for Dynamics			
Loading	Definitions		
Analysis	Primary Load Moving Load Generation		
Post-Analysis Print	Lead Combination		
Design	Automatic Load Combination		
Miscelianeous	Lead Commands		
-	Define Primary Load Types Load List		
	Edit Auto Load Rules		
			New. Add. Eift Deist Togge Laad Assignment Method Assign To Stelacted Entries Assign To Wew Assign To Eift I
			Assign Cose He
	Mender Dickess Mender Providess Mender Providess Mender Providess Mender Providess Support Specifications Mender Mende	Linker Takiters Merker Trainers Merker Trainers Merker Trainers Merker Trainers Merker Specifications Merker Specificat	Unified Theorem Image: Transmit Constraints Member Transmit Image: Transmit Constraints Member Transmit Constraints MetVincel Structure Member Transmit Constraints MetVincel Structure Member Transmit Constraints MetVincel Structure MetVince Transmit Constraints MetVincel Structure MetVince Transmit Constraints MetVincel Structure MetVince Transmit Constraints MetVince Structure MetVince Transmit Constraints MetVince Structure MetVince Structure Image: Leaf Generation. Metvince Constraints Leaf Constraints. Metvince Structure Image: Leaf Generation. Metvince Structure Leaf Constraints. Metvince Structure Leaf Constraints. Metvince Structure Leaf Constraints. Metvince Structure Leaf Constraints. Ext Aute Leaf Rules Ext Aute Leaf Rules

Number 1 , Loading type 'DEAD' , Title 'Load Case 1' , Add , Close

5 II Ø	₿ Კ 🕲 ฿ ଈ ଈ ₦ G		
4 Modeling	Postprocessing Steel Design	Concrete Design Foundation Design RAM Connection Bridge Deck Advanced Slab Design Plping E	arthquake
najyss/Print 20 overset at 20 Geometry 70 Setup d & Definition 2- Support 25 Spec H-Property	2	CC Create New Definitions / Load Cases / Load Rems:	Load & Definition
Big Material	Ý Ž-X	Add Core Hep	New Add. Eff

Now click on ' Load case 1 ' , New , Load Items , Member load , Uniform Load , W1 , -2 knm Add



Then Concentrated force P -5 d1 3 Add , then P -8 d1 2.5 Add close Now click on UNI GY -2 kn/m 'use cursor to Assign, Click on first Span.



Similarly assign 5kn and 8Kn on remaining two spans and then click close To verify whether all loads are assigned correctly or not Click on Load details menu on menu bar And click load view, now load diagram with values should be seen on main diagram.



10. Now Commands\Analysis\Perform Analysis, select all, ok.

File Edit View Tools Select Geometr	y Commands Analyze Mode Windo Plate Thickness		BRRP OUT	
68888886 + + +	↓ Surface Thickness Member Property	, C Q ID gt Q ♠ 1: LOAD CASE 1	1	
<mark>∕₄%≌02333008</mark> a€a	Material Constants Geometric Constants	→ 9° 🔞 🧐 J 💲 🚽 🗖 🗖 🚺	\$ 1	
N. Modeling Postprocessing Ste	Support Specifications	Design RAM Connection Bridge Deck Advance	d Slab Design Piping Earthqu	ake
	Member Specifications Plate Element Specifications	AM - Whole Structure		Load & Definition
Prope 28	Master/Slave Specification	•		Definitions Load Cases Details
XX _ I	Pre Analysis Print	•		IL 1 LOAD CASE 1 UNI GY -2kN/m
Spec spec	hot Define Damping for Dynamics			CONGY-53kNm
A 8 00	Loading	•		Load Envelopes
14 a 5	Analysis	 Perform Analysis 		
Supp Participation	Post-Analysis Print	P-Delta Analysis Non-Linear Analysis		
÷ 炎 📩	Design	Perform Direct Analysis		
in the second se	Miscellaneous	Perform Buckling Analysis		
d a Detir		Perform Cable Analysis Perform Imperfection Analysis Perform Pushover Analysis	<u>a</u>	
H 0		Change		
# 5 m		Clear Above Commands		New Add Edt Delete
Attest Des		·		asignment Method
				Assign To Selected Entities Assign To Vew Assign To Vew
No. In the second secon				1
2×			Load 1	Assign Close Help
			,	fodeling Mo Load 1 : LOAD CASE 1 Input Units: kN-
📫 🙆 🚞 🧔	🗉 🔕 🚺 💷	1 A A A A A A A A A A A A A A A A A A A	STIL 111116	▲ 🗰 🏴 🔒 🏜 ENG 02:41 PM 30-07-201

11. Now Click Analysis\Run analysis Click Staad Analysis After a time, display will show number of errors & warning messages if anythen

00000000 *€\$		P (* O A 1 1040 CASE 1						
todeling Po:	Reading Member Properties Finished Reading Member Properties Processing Support Condition. Read/Check Data in Load Cases	14:43:26 ^ 90 ms 14:43:26 14:43:26	ck Advanced Slab Design Piping E	arthquake				
e 🗉 🗖 🕂	Using In-Core Advanced Solver				CON	TINUOUS	BEAM	0 0
8 8 ++	Processing and setting up Load Vector.	14:43:27				x	Y	Z
: _ ++	Processing Element Stiffness Natrix.	14:43:28			Node	m	m	m
	Calculating Member Forces.	14:43:28			1	0.000	0.000	0.000
	Analysis Successfully Completed ++				2	6.000	0.000	0.000
	Creating Displacement File (DSP)	14:43:29			3	11.000	0.000	0.000
- ++	Creating Reaction File (REA)	14:43:29			4	16.000	0.000	0.000
	I M COLLMENT INCO. THE COLLMENT WILL ME THE							
	Calculating Conting Frances	14:43:29			5			
- 13	Calculating Section Forces2.	14:43:29 14:43:29			5			
10 10 10 10 10 10 10 10 10 10 10 10 10 1	Calculating Section Forces 1 Creating Section Force File (BMD) Creating Section Displace File (SCN) Done.	14 : 43 : 29 14 : 43 : 30			5			
	Calculating Section Forces2 Creating Section Force File (RMD). Creating Section Displace File (SCN) Done. Done. Or(s). 0 Warning(s). 0 Note(s) End STAAD. Pro Run Elapsed Time = 5 Secs	14:43:29 14:43:29 14:43:29 14:43:29 14:43:30				TINUOUS	BEAM	
+++ + + + + + + + + + + + + + + + + +	Calculating Section Forces? Creating Section Force File (SMD) Creating Section Displace File (SCN) Done. Torr(s). 0 Varning(s). 0 Note(s) End STAAD Pro Run Elapsed Time = CONTINUOU	14:43:29 14:43:29 14:43:29 14:43:29 14:43:30			5 CON	TINUOUS Node A	BEAM	Property Re
+++ +++ +++ +++ +++ +++ +++ +++ +++++++	Calculating Section Forces? Creating Section Proce File (SCN) Creating Section Displace File (SCN) Dome. ror(s), 0 Varning(s). 0 Note(s) End STAAD Pro Run Elapsed Time = 5 Secs CONTINUOU	14:43:29 14:43:29 14:43:29 14:43:29 14:43:30	Ł		S CON	TINUOUS Node A	BEAM Node B	Property Re
+++++++++++++++++++++++++++++++++++++	Calculating Section Percess. Creating Section Property (MBD) Creating Section Displace File (SCH) Dome. eror(s). 0 Warning(s). 0 Note(s) End STAAD Pro Run Elapsed Time + 5 Secs CONTINUOU Voldad FM	14:43:29 14:43:29 14:43:29 14:43:29 14:43:30 5 BEAM.enl	4		5 CON Beam 1 2	ITINUOUS Node A	BEAM Node B 2 3	Property Re
+++ +++ +++ +++ ++ ++ ++ ++ ++ ++ ++ ++	Calculating Section Forces? Creating Section Properla Creating Section Displace File (SCN) Done. err(s), 0 Varning(s), 0 Note(s) End STAAD Pro Run Elapsed Time = 5 Sector CONTINUOU VOIdou FM o Fult Processy Mode	14:43:29 14:43:29 14:43:29 14:43:29 14:43:29 14:43:30	Ł		5 CON Beam 1 2 3	ITINUOUS Node A 1 2 3	BEAM Node B 2 3 4	Property Re 1 1 2
1001 • Paranee • • Sold ■ Surt + + + + + + + + + + + + + + + + + + +	Calculating Section Percend. Creating Section Prop File (SCN) Creating Section Displace File (SCN) Done. error(s). 0 Warning(s). 0 Note(s) End STAAD Pro Run Elapsed Time - S Sece CONTINUOU VOIdou File Pold Programs S Sece CONTINUOU VOID POL S Sece CONTINUOU	14:43:29 14:43:29 14:43:29 14:43:29 14:43:20 14:43:30 5 BEAM onl	Ł	7	5 CON Beam 1 2 3 4	ITINUOUS Node A 1 2 3	BEAM Node B 2 3 4	Property Re
t ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ± ±	Calculating Section Forces? Creating Section Property Creating Section Displace File (SCN) Creating Section Displace File (SCN) Done. For (s), 0 Verning(s), 0 Note(s) End STAAD Pro Run Elepsed Time = 5 Sector CONTINUOU VOIdou File Pro Runcessy Mode ra Modeling Mode	14 (43) 29 14 (43) 29 14 (43) 29 14 (43) 29 14 (43) 29 14 (43) 30 5 BEAM enl	Ł		5 CON Beam 1 2 3 4	TINUOUS Node A 1 2 3	BEAM Node B 2 3 4	Property Re 1 2
1 Compos eParame	Calculating Section Forces1. Creating Section Property Creating Section Displace File (SCN) Creating Section Displace File (SCN) Done. For (s). 0 Warning(s). 0 Note(s) End STAAD Pro Run Elepsed Time = 5 Sece CONTINUOU CONTAGE CONTINUOU Control File Programs Mode In Modely Mode	14:43:29 14:43:29 14:43:29 14:43:29 14:43:20 14:43:30 5 BEAM onl	7		5 CON Beam 1 2 3 4	TINUOUS Hode A 1 2 3	BEAM Node B 2 3 4	Property Re
+++++++++++++++++++++++++++++++++++++	Calculating Section Parces2. Creating Section Property Creating Section Displace File (SOI) Creating Section Displace File (SOI) End STAAD Pro Run Elapsed Time * 5 Sec contributor * 5 Sec contributor * 5 Sec contributor * 5 Sec *	14 43 29 14 43 29 16 43 20 16 44 20 160	4		5 Beam 1 2 3 4	TINUOUS Node A 1 2 3	BEAM Node B 2 3 4	Property Re 1 2
1 (Compos 1 (C	Calculating Section Forces1. Creating Section Property Creating Section Displace File (SCN) Creating Section Displace File (SCN) Done. cor(s). 0 Warning(s). 0 Note(s) End STAAD Pro Run Elapsed Time - S Sece CONTINUOU CONTACT File o Fund Processog Mode o Fund Processog Mode o Modely Mode	14 43 29 14 43 29 14 42 29 14 43 29 14 43 29 14 43 29 14 43 29 14 43 30 5 HEAM an1			5 Beam 1 2 3 4	TINUOUS Node A 1 2 3	BEAM Node B 2 3 4	Property Re 1 1 2
pea	Calculating Section Percess. Creating Section Properties (BMD) Creating Section Displace File (SCH) Dome. eror(s). 0 Warning(s). 0 Note(s) End STAAD Pro Nun Elepsed Time * Sece CONTINUOU Voltad File Pad Processy Mode an Modery Mode	14 43 29 14 43 29 14 43 29 14 43 29 14 43 30 B HEAM and Y			5 CON	TINUOUS Node A 1 2 3	BEAM Node B 2 3 4	Property Re
Mypta	Calculating Section Forces1. Creating Section Property (MM) Creating Section Displace File (SCN) Done. enr(s), 0 Varning(s). 0 Note(s) End STAAD Pro Run Elapsed Time - S Sece CONTINUOU Control File o Part Processor Mode o Modeling Mode	14 43 29 14 43 29 14 43 29 14 43 29 14 43 29 14 43 30 5 BEAH an1		Load 1	5 Beam 1 2 3 4	TINUOUS Hode A 1 2 3	BEAM Node B 2 3 4	Property Ru 1 1 2

Page | 20

Now Staad pro has executed analysis of continuous beam and the results of the analysis are to be seen on Post processing mode.



The post processing mode window will appear as shown in the fig. Below.



12. To see the bending moment diagram of the analysed beam click on the <u>beam</u>tab at left side of the working window. Click on <u>Mz</u>button on the menu bar at top of the working window. You shouldsee the BMD as shown in the figure below(Holding down the ctrl button scroll the mouse wheel to adjust the scale to your convenience). Go to reactions menu>>view value >>beam results and check the boxes ends, maximum and midpoint under bending to see the value of BMD at respective locations.



13. To see the shear force diagram click on the <u>beam</u>tab at left side of the working window. Click on <u>Fy</u>button on the menu bar at top of the working window. You should see the SFD as shown in the figure below (Holding down the ctrl button scroll the mouse wheel to adjust the scale to your convenience). Go to reactions menu>>view value >>beam results and check the boxes ends, maximum and midpoint under shear to see the value of SFD at



respectivelocations.

- 14. To see the displacement of the beam click on the **nodes>displacement** tab in the menu on left side of the working area. You should see the diagram as shown in the figure below(Holding down the **ctrl** button scroll the **mouse wheel** to adjust the scale to your convenience). To view the displacement value you can go to **reactions** menu>>**view value >>beam results** and check the box **Max resultant** under**displacement**.
- 15. To see the reactions at the support of the beam go to **nodes>>reactions** tab on left side of the working area.

Result:

Pre-Viva Questions:

- 1. Define a Continuous beam.
- 2. What are the different types of supports used in Continuous beam?
- 3. What type of loads used on continuous beam?
- 4. What is the bending moment at hinge support?
- 5. How to create the supports?

Post Viva Questions:

- 1. How to see B.M.D in Continuous beam?
- 2. How to see S.F.D in Continuous beam?
- 3. Where to see the Results?
- 4. How many types of loads are there?
- 5. What is Selfweight of beam?

EXPERIMENT NO: 3

ANALYSIS AND DESIGN OF SINGLE-STOREY FRAME

Aim: To analyze the single storeyed space frame using STADD pro

Hardware & software required:

Computer with specified configuration with installed STADD Pro Software

PROCUDURE AND ANALYSIS STEPS:

Staad foundation:

Staad foundation is a powerful tool used to calculate different types of foundations. It is also licensed by Bentley software's. All Bentley software's cost about 10 lakhs and so allengineers can't use it due to heavy cost.

Analysis and design carried in Staad and post processing in staad gives the load atvarious supports. These supports are to be imported into these software to calculate the footingdetails i.e., regarding the geometry and reinforcement details.

This software can deal different types of foundations

SHALLOW (D<B)

1. Isolated (Spread) Footing

- 2. Combined (Strip) Footing
- 3. Mat (Raft) Foundation

DEEP (D>B)

1. Pile Cap

2. Driller Pier

1. Isolated footing is spread footing which is common type of footing.

2. Combined Footing or Strap footing is generally laid when two columns are very near to each other.

3. Mat foundation is generally laid at places where soil has less soil bearing capacity.

4. pile foundation is laid at places with very loose soils and where deep excavations are required.

So depending on the soil at type we has to decide the type of foundation required. Also lot of input data is required regarding safety factors, soil, materials used should begiven in respective units. After input data is give software design the details for each and every footing and gives the details regarding

1. Geometry of footing

2. Reinforcement

3. Column layout

- 4. Graphs
- 5. Manual calculations

These details will be given in detail for each and every column.

Another advantage of foundations is even after the design; properties of the members can beupdated if required.

The following properties can be updated

Column Position

Column Shape

Column Size

Load Cases

Support List

The multistoreyed frame represents the center line diagram of the building in staad pro. Eachsupport represents the location of different columns in the structure. This structure is used ingenerating the entire structure using a tool called transitional repeat and link steps. After using the tool the structure that is created can be analyzed in staad pro under various loading cases.

Below figure represents the skeletal structure of the building which is used to carry out theanalysis of our building. All the loadings are acted on this skeletal structure to carry out the analysis of our building. This is not the actual structure but just represents the outline of the building in staad pro.

A mesh is automatically created for the analysis of these building.

PROCUDURE AND ANALYSIS STEPS:

Staad foundation:

Staad foundation is a powerful tool used to calculate different types of foundations. It is also licensed by Bentley software's. All Bentley software's cost about 10 lakhs and so allengineers can't use it due to heavy cost.

Analysis and design carried in Staad and post processing in staad gives the load atvarious supports. These supports are to be imported into these software to calculate the footingdetails i.e., regarding the geometry and reinforcement details.

This software can deal different types of foundations

SHALLOW (D<B)

1. Isolated (Spread) Footing

2. Combined (Strip) Footing

3. Mat (Raft) Foundation

DEEP (D>B)

1. Pile Cap

2. Driller Pier

1. Isolated footing is spread footing which is common type of footing.

2. Combined Footing or Strap footing is generally laid when two columns are very near to each other.

3. Mat foundation is generally laid at places where soil has less soil bearing capacity.

4. Pile foundation is laid at places with very loose soils and where deep excavations are required.

So depending on the soil at type we has to decide the type of foundation required. Also lot of input data is required regarding safety factors, soil, materials used should begiven in respective units. After input data is give software design the details for each and every footing and gives the details regarding

- 1. Geometry of footing
- 2. Reinforcement
- 3. Column layout
- 4. Graphs
- 5. Manual calculations

These details will be given in detail for each and every column.

Another advantage of foundations is even after the design; properties of the members can beupdated if required.

The following properties can be updated

Column Position

Column Shape

Column Size

Load Cases

Support List

The multistoreyed frame represents the center line diagram of the building in staad pro. Eachsupport represents the location of different columns in the structure. This structure is used ingenerating the entire structure using a tool called transitional repeat and link steps. After using the tool the structure that is created can be analyzed in staad pro under various loading cases.

Below figure represents the skeletal structure of the building which is used to carry out theanalysis of our building. All the loadings are acted on this skeletal structure to carry out the analysis of our building. This is not the actual structure but just represents the outline of the building in staad pro.

A mesh is automatically created for the analysis of these building.

PROCUDURE AND ANALYSIS STEPS:

Staad foundation:

Staad foundation is a powerful tool used to calculate different types of foundations. It is also licensed by Bentley software's. All Bentley software's cost about 10 lakhs and so allengineers can't use it due to heavy cost.

Analysis and design carried in Staad and post processing in staad gives the load atvarious supports. These supports are to be imported into these software to calculate the footing details i.e., regarding the geometry and reinforcement details.

This software can deal different types of foundations

SHALLOW (D<B)

1. Isolated (Spread) Footing

2. Combined (Strip) Footing

3. Mat (Raft) Foundation

DEEP (D>B)

1. Pile Cap

2. Driller Pier

1. Isolated footing is spread footing which is common type of footing.

2. Combined Footing or Strap footing is generally laid when two columns are very near to each other.

3. Mat foundation is generally laid at places where soil has less soil bearing capacity.

4. pile foundation is laid at places with very loose soils and where deep excavations are required.

So depending on the soil at type we has to decide the type of foundation required. Also lot of input data is required regarding safety factors, soil, materials used should begiven in respective units. After input data is give software design the details for each and every footing and gives the details regarding

1. Geometry of footing

2. Reinforcement

3. Column layout

- 4. Graphs
- 5. Manual calculations

These details will be given in detail for each and every column.

Another advantage of foundations is even after the design; properties of the members can beupdated if required.

The following properties can be updated

Column Position

Column Shape

Column Size

Load Cases

Support List

The multistoreyed frame represents the center line diagram of the building in staad pro. Eachsupport represents the location of different columns in the structure. This structure is used ingenerating the entire structure using a tool called transitional repeat and link steps. After using the tool the structure that is created can be analyzed in staad pro under various loading cases.

Below figure represents the skeletal structure of the building which is used to carry out theanalysis of our building. All the loadings are acted on this skeletal structure to carry out the analysis of our building. This is not the actual structure but just represents the outline of the building in staad pro.



A mesh is automatically created for the analysis of these building.

Load Conditions and Structural System Response :

The concepts presented in this section provide an overview of building loads and theireffect on the structural response of typical wood-framed homes. As shown in Table, buildingloads can be divided into types based on the orientation of the structural action or forces that theyinduce: vertical and horizontal (i.e., lateral) loads. Classification of loads are described in thefollowing sections.

Building Loads Categorized by Orientation:

Types of loads on an hypothetical building are as follows.

Vertical Loads

Dead (gravity)

Live (gravity)

Snow(gravity)

Wind(uplift on roof)

Seismic and wind (overturning)

Seismic(vertical ground motion)

Horizontal (Lateral) Loads:

Direction of loads is horizontal w.r.t to the building.

Wind

Seismic(horizontal ground motion)

Flood(static and dynamic hydraulic forces

Soil(active lateral pressure)

Dead load calculation

Weight=Volume x Density

Self weight floor finish=0.12*25+1=3kn/m^2

The above example shows a sample calculation of dead load.

Dead load is calculated as per IS 875 part 1

Generally for any structure live load is taken as 25 N/mm for design.

Live loads are calculated as per IS 875 part 2

Wind loads:

In the list of loads we can see wind load is present both in vertical and horizontal loads. This is because wind load causes uplift of the roof by creating a negative(suction) pressure on the top of the roofAfter designing wind load can be assigned in two ways

1. Collecting the standard values of load intensities for a particular heights and assigning of theloads for respective height.

2. Calculation of wind load as per IS 875 part 3.

We designed our structure using second method which involves the calculation of wind loadusing wind speed. In Hyderabad we have a wind speed of 45 kmph for 10 m height and this value is used inCalculation.

Floor load:

Floor load is calculated based on the load on the slabs. Assignment of floor load is doneby

creating a load case for floor load. After the assignment of floor load our structure looks asshown in the below figure.

The intensity of the floor load taken is: 0.0035 N/mm2

-ve sign indicates that floor load is acting downwards

Load combinations:

All the load cases are tested by taking load factors and analyzing the building in differentload combination as per **IS456** and analyzed the building for all the load combinations and results are taken and maximum load combination is selected for the design Load factors as per **IS456-2000**

When the building is designed for both wind and seismic loads maximum of both is taken.

Live load	dead load	wind load
1.5	1.5	0
1.2	1.2	1.2
0.9	0.9	0.9

Because wind and seismic do not come at same time as per code. Structure is analyzed by taking all the above combinations.

Result:

Pre-Viva Questions:

- 1. How many typespf models are available in structure wizard?
- 2. How can you import the AUTO CAD drawings into STAAD pro?
- 3. What are the different types of analysis in STAAD pro?
- 4. In how many ways can we assign support to nodes?
- 5. In STAAD pro we have only add beam tool but not add column then how can we add columns?

Post Viva Questions:

- 6. What is the name of extension file of STAAD pro?
- 7. How many types of meshing we have in STAAD pro?
- 8. How to select beams in staad.pro?
- 9. STAAD pro perform analysis is?
- 10. Who invented STAAD pro?

EXPERIMENT NO: 4

ANALYSIS OF MULTI-STOREY FRAME

Aim: To analyze the Multi storeyed space frame using STADD pro

HARDWARE & SOFTWARE REQUIRED:

Computer with specified configuration with installed STADD Pro Software

PROCUDURE AND ANALYSIS STEPS:

Staad foundation:

Staad foundation is a powerful tool used to calculate different types of foundations. It is also licensed by Bentley software's. All Bentley software's cost about 10 lakhs and so allengineers can't use it due to heavy cost.

Analysis and design carried in Staad and post processing in staad gives the load atvarious supports. These supports are to be imported into these software to calculate the footingdetails i.e., regarding the geometry and reinforcement details.

This software can deal different types of foundations

SHALLOW (D<B)

1. Isolated (Spread) Footing

- 2. Combined (Strip) Footing
- 3. Mat (Raft) Foundation

DEEP (D>B)

- 1. Pile Cap
- 2. Driller Pier

1. Isolated footing is spread footing which is common type of footing.

2. Combined Footing or Strap footing is generally laid when two columns are very near to each other.

3. Mat foundation is generally laid at places where soil has less soil bearing capacity.

4. pile foundation is laid at places with very loose soils and where deep excavations are required.

So depending on the soil at type we has to decide the type of foundation required. Also lot of input data is required regarding safety factors, soil, materials used should begiven in respective units. After input data is give software design the details for each and every footing and gives the details regarding 1. Geometry of footing

- 2. Reinforcement
- 3. Column layout
- 4. Graphs
- 5. Manual calculations

These details will be given in detail for each and every column.

Another advantage of foundations is even after the design; properties of the members can beupdated if required.

The following properties can be updated

Column Position

Column Shape

Column Size

Load Cases

Support List

The multistoreyed frame represents the center line diagram of the building in staad pro. Eachsupport represents the location of different columns in the structure. This structure is used ingenerating the entire structure using a tool called transitional repeat and link steps. After using the tool the structure that is created can be analyzed in staad pro under various loading cases.

Below figure represents the skeletal structure of the building which is used to carry out theanalysis of our building. All the loadings are acted on this skeletal structure to carry out the analysis of our building. This is not the actual structure but just represents the outline of the building in staad pro.

A mesh is automatically created for the analysis of these building.



Load Conditions and Structural System Response :

The concepts presented in this section provide an overview of building loads and theireffect on the structural response of typical wood-framed homes. As shown in Table, buildingloads can be divided into types based on the orientation of the structural action or forces that theyinduce: vertical and horizontal (i.e., lateral) loads. Classification of loads are described in thefollowing sections.

Building Loads Categorized by Orientation:

Types of loads on an hypothetical building are as follows.

Vertical Loads

Dead (gravity)

Live (gravity)

Snow(gravity)

Wind(uplift on roof)

Seismic and wind (overturning)

Seismic(vertical ground motion)

Horizontal (Lateral) Loads:

Direction of loads is horizontal w.r.t to the building.

Wind

Seismic(horizontal ground motion)

Flood(static and dynamic hydraulic forces

Soil(active lateral pressure)

Dead load calculation

Weight=Volume x Density

Self weight floor finish=0.12*25+1=3kn/m^2

The above example shows a sample calculation of dead load.

Dead load is calculated as per IS 875 part 1

Generally for any structure live load is taken as 25 N/mm for design.

Live loads are calculated as per **IS 875 part 2**

Wind loads:

In the list of loads we can see wind load is present both in vertical and horizontal loads. This is because wind load causes uplift of the roof by creating a negative(suction) pressure on the top of the roofAfter designing wind load can be assigned in two ways

1. Collecting the standard values of load intensities for a particular heights and assigning of theloads for respective height.

2. Calculation of wind load as per IS 875 part 3.

We designed our structure using second method which involves the calculation of wind loadusing wind speed. In Hyderabad we have a wind speed of 45 kmph for 10 m height and this value is used inCalculation.

Floor load:

Floor load is calculated based on the load on the slabs. Assignment of floor load is doneby creating a load case for floor load. After the assignment of floor load our structure looks asshown in the below figure.

The intensity of the floor load taken is: 0.0035 N/mm2

-ve sign indicates that floor load is acting downwards

Load combinations:

All the load cases are tested by taking load factors and analyzing the building in differentload combination as per **IS456** and analyzed the building for all the load combinations and results are taken and maximum load combination is selected for the design Load factors as per **IS456-2000**

When the building is designed for both wind and seismic loads maximum of both is taken.

Live load	dead load	wind load
1.5	1.5	0
1.2	1.2	1.2
0.9	0.9	0.9

Because wind and seismic do not come at same time as per code. Structure is analyzed by taking all the above combinations. **Result:**

Pre-Viva Questions:

- 1. What type of Columns we can use?
- 2. What is Dead load?
- 3. What is Live load?
- 4. What is wind load?
- 5. What is code book for RCC design?

Post Viva Questions:

- 1. What is earth quake load?
- 2. What is floor load?
- 3. What is the difference between design and analysis?
- 4. How to select nodes in staad.pro
- 5. How to select beams in staad.pro

EXPERIMENT NO: 5

DESIGN OF MULTI-STOREY FRAME

Aim: Analyze the following 7-Storied residential building under all loads and Columns, Beams forces and support reactions for foundation design

Software required:

STAAD PRO V8i



column layout plan and beam layout plan



Elevation view

Geometry and Loads:

Properties:	Load Definitions:		
Column: C1= 12"X15"	1. Seismic Definition: (Dhaka zone)		
C2=12"X18"	EQx & EQz		
C3=12"X20"	2. Wind Definitions: (for Dhaka)		
	Wx & Wz		
Beam: GB = 10"X18"	*Wind speed for Dhaka zone = 210 km/hr = 130 mile/hr		
FB = 10"X20"	3. Dead Load:		
Varenda Beam: 6" X 6"	Self weight (Factor=1)		
	Slab weight = 75 psf (For slab thickness= 6")		
 All supports are fixed support 	Floor Finish (FF) = 30 psf		
 Bottom story height = 8'-0" 	Partition wall load (PW) = 25 psf		
 Typical story height = 10'-0" 	Wall load on beams (W) = 416 Ib/ft (for 5" brick wall)		
 Top story for lift & stair = 8'-0" 	4. Live Load: LL = 40 psf		
	Load Combinations:		
	UFL = DL+LL		
	FDL = 1.2*DL+1.6*LL		
	FDLEQx = 0.9*DL+1.2*LL+1.32*EQx		
	FDLEQz = 0.9*DL+1.2*LL+1.32*EQz		
	FDLWx = 0.9*DL+1.2*LL+1.2*Wx		
	FDLWz = 0.9*DL+1.2*LL+1.2*Wz		

Procedure:

Geometry (Model creating):

Open the STAAD Pro. software and click on New Project -Space >File name >Location (select your file location to save) >Length unit select Foot and KiloPound>Next >Add Beam >Finish. 1.2 Column & Beam Layout: 1.2.1 Close the default Grid system and at the right side input your first node point coordinates as (X Y Z)=(0 0 0)

After than select the node by using node cursor >Geometry >Translational Repeat >Select Global Direction = X > No of Steps = 3 >now write down the column spacing from your Column Layout Plan as (Step1 =19.5, Step2 =8.5, Step3 =19.5) >Link Steps >OK.

After than select the total beam by using Beam cursor >Geometry >Translational Repeat >Select Global Direction = Z >No of Steps = 1 >now write down the column spacing from your Column Layout Plan as (Step1 =15.667 ft) >Link Steps >OK.

Now select the column node no 5 & 8 from the 2nd row >Geometry >Translational Repeat >Select Global Direction = Z > No of Steps =2 > now write down the column spacing from your Column Layout Plan as (Step1 =12.25, Step2 =11) \Box OK

Again select the column node no 9 & 10 by using node cursor >Geometry >Translational Repeat >Select Global Direction = X > No of Steps =3 >now write down the column spacing from your Column Layout Plan as (Step1 =13.25, Step2 =21, Step1 =13.25) >OK






- For create beam layout: Go to Geometry >Add Beam >Add Beam from Point top Point and then connect the nodes points each other as the given Beam layout plan. Again for interesting beam go to Geometry >Add Beam >Add Beam by Perpendicular Intersection
- Veranda Create: Now select the node no 12 >Geometry >Trtranslational Repeat □ Select Global Direction = X> No of Steps =1 > now write down the Veranda length as (Step1 = -10.5) >OK
- Again select the beam from node no 12 to 19 by using beams cursor
 >Geometry >Translational Repeat >Select Global Direction = Z > No of

Steps =1 >now write down the now write down the Veranda width as (Step1 =3) >Click on Link Steps >OK (Figure: 5.9). And similarly create another Veranda.

Now Story Create: Select whole structure >Geometry >Translational Repeat
 >Select Global Direction = Y> No of Steps =8(7 stoy+1 is bottom story for base)>Default Step Spacing = 10(Typical story height) and Step1 = 8)
 >Click on Link Steps >OK

General (Define & Assign):

Support Create and Assign:

Click on View from +Z >Select the all bottom Story beams >Delete>Ok >Yes

From left side Click on General >Support >Create > Fixed >Add

Select S2 Support 2 >Select all bottom Nodes by using Node Cursor >Assign to Selected Nodes >Assign >Yes.





Result:

Pre-Viva Questions:

- 1. What is IS 875 (Part1)?
- 2. What is IS 875 (Part2)?
- 3. In which code you see wind loads?
- 4. In which code you see earth quake loads?
- 5. What is self weight of structure?

- 1. What is floor load?
- 2. How to apply foor load?
- 3. What is loadcombination?
- 4. How to see the front view?
- 5. What is global direction?

EXPERIMENT NO: 6

ANALYSIS OF MULTI-STOREYBUILDING

Aim: To create and analyze the multi storey building by using STAAD Pro

Software required:

STAAD PRO V8i

Procedure in STAAD Pro:

Preprocessing:

- 1. Create model
 - a) New project> plane> length units as m> force units asKN>type the file name as multi storey building>next> add beam.
 - b) Geometry> run structural wizard> frame model> bay frame>type the length as 12.6, no.of bays along length as 3, height as 12.6, no. of bays along height as 4> apply & transfer the model to STAAD Pro screen.
- 2. Property
 - a) General> property> define> rectangular>0.35x 0.23> add> close
 - b) Select rectangular and assign to view.
- 3. Support

Support> fixed support> select the bottom nodes> assign selected nodes.

- 4. Loads
 - a) Load and definition> load case detail> add>change the title as DL>add> then change LL> add> WL> add> close.
 - b) Select DL> add> member load> uniform load> type W1 as -40KN/m < add.
 - c) Select LL > add> member load> uniform load> type W1 as -20KN/m < add.
 - d) Select WL > add> nodal load> type X as 25> add> type X as 20> add> type X as 15> add> type X as 10> add>close>Select DL> click select > member parallel to x direction> assign selected beams.
 - e) Similarly, click select > member parallel to x direction> assign selected beams.
 - f) WL> select node cursor> select the particular node> assign selected node.

For load combinations, go to load case details> add> define combination> type name as DL+LL> FOS as 1.5>in available load case, select DL & LL and send it other side> add. Select DL & LL and send it other side> add.



Postprocessing

- g) Then similarly type name as DL+LL+WL> FOS as 1.5>in available load case, select DL, LL & WL and send it other side> add. Select DL, LL& WL and send it other side> add.
- h) Then similarly type name as DL+LL-WL> FOS as 1.5>in available load case, select DL, LL & WL and send it other side> add. Select DL & LL and send it other side> add. After that select WL and send it other side> add.
- i) Then similarly type name as DL+LL+WL> FOS as 1.2>in available load case, select DL,
 LL & WL and send it other side> add. Select DL, LL& WL and send it other side> add.

5. Design parameters

- a) Design concrete> IS 456>define parameter> give Fc as 20000 KN/m2 for M20 concrete
 >Fc as 30000 KN/m2 for M30 concrete>add> FY as 415000 KN/m2> add> select> ratio as 3>add.
 - b) Then go to commands>design beam> add>design column> add>take off > close.
 - c) Select Fc> select entire structure using cursor> assign it to selected beams> similarly do it for FY and ratio then assign it.

d) For beams > select the beams parallel to x direction and for columns column parallel to y direction and then assign it.

6. Analysis:

Analysis& print> add> close>analyze> run analyze> save> post processing> done. Post-processing:

a) In post-processing you have to see the deflection, bending moment, shear, axial forces, stresses and everything by turn on the particular specified icons for all the load combinations already given.

- b) Results> view value> beam results> maximum displacement> activate.
- c) You can also see the animations of displacement in it.

Result:

Pre-Viva Questions:

- 1. What is translational repeat?
- 2. What is circular translational repeat?
- 3. What is theorem of three moments?
- 4. What are the various types of loads?
- 5. What is code book for RCC design?

- 1. What is S.C.C.?
- 2. What is the density of steel?
- 3. Explain the abbreviation for Staad.pro
- 4. What is mix proportion?
- 5. How to select a floor?

EXPERIMENT NO: 7

DESIGN OF MULTI-STOREY BUILDING

Aim:

To design the multi storey building by using STAAD Pro

Software required:

STAAD PRO V8i

Procedure in STAAD Pro:

Preprocessing:

- 1. Create model
 - a) New project> plane> length units as m> force units asKN>type the file name as multi storey building>next> add beam.
 - b) Geometry> run structural wizard> frame model> bay frame>type the length as 12.6, no.of bays along length as 3, height as 12.6, no. of bays along height as 4> apply & transfer the model to STAAD Pro screen.
- 2. Property
 - a) General> property> define> rectangular>0.35x 0.23> add> close
 - b) Select rectangular and assign to view.
- 3. Support

Support> fixed support> select the bottom nodes> assign selected nodes.

- 4. Loads
 - a) Load and definition> load case detail> add>change the title as DL>add> then change LL> add> WL> add> close.
 - b) Select DL> add> member load> uniform load> type W1 as -40KN/m < add.
 - c) Select LL > add> member load> uniform load> type W1 as -20KN/m < add.
 - d) Select WL > add> nodal load> type X as 25> add> type X as 20> add> type X as 15> add> type X as 10> add>close>Select DL> click select > member parallel to x direction> assign selected beams.
 - e) Similarly, click select > member parallel to x direction> assign selected beams.
 - f) WL> select node cursor> select the particular node> assign selected node.

For load combinations, go to load case details> add> define combination> type name as DL+LL> FOS as 1.5>in available load case, select DL & LL and send it other side> add. Select DL & LL and send it other side> add.

- 5. Post processing
 - a) Then similarly type name as DL+LL+WL> FOS as 1.5>in available load case, select DL,
 LL & WL and send it other side> add. Select DL, LL& WL and send it other side> add.
 - b) Then similarly type name as DL+LL-WL> FOS as 1.5>in available load case, select DL, LL & WL and send it other side> add. Select DL & LL and send it other side> add. After that select WL and send it other side> add.
 - c) Then similarly type name as DL+LL+WL> FOS as 1.2>in available load case, select DL, LL & WL and send it other side> add. Select DL, LL& WL and send it other side> add.
- 6. Design parameters
 - a) Design concrete> IS 456>define parameter> give Fc as 20000 KN/m2 for M20 concrete >Fc as 30000 KN/m2 for M30 concrete>add> FY as 415000 KN/m2> add> select> ratio as 3>add.
 - b) Then go to commands>design beam> add>design column> add>take off > close.
 - c) Select Fc> select entire structure using cursor> assign it to selected beams> similarly do it for FY and ratio then assign it.
 - d) For beams > select the beams parallel to x direction and for columns column parallel to y direction and then assign it.

6. Analysis:

Analysis& print> add> close> analyze> run analyze> save> post processing> done.

Post-processing:

a) In post-processing you have to see the deflection, bending moment, shear, axial forces, stresses and everything by turn on the particular specified icons for all the load combinations already given.

- b) Results> view value> beam results> maximum displacement> activate.
- c) You can also see the animations of displacement in it.

Result:

Pre-Viva Questions:

- 1. What is the min steel in column?
- 2. What is min steel in slab?
- **3**. What is M20?
- 4. What is duplicate beams?
- 5. What is duplicate nodes?

- 1. In how many ways we can assign supports to nodes.
- 2. Is Staad pro a finite element analysis?
- 3. How many codes are there in Staad pro?
- 4. Why Staad pro used?
- 5. How to select columns?

EXPERIMENT NO: 8

WIND LOAD ANALYSIS ON RCC BUILDING

Aim: To analyze the RCC building by using STAAD Pro.

Software required:

STAAD PRO V8i

Procedure in STAAD Pro:

Geometry (Model creating):

Open the STAAD Pro. software and click on New Project -Space >File name >Location (select your file location to save) >Length unit select Foot and KiloPound>Next >Add Beam >Finish.

Column & Beam Layout:

Close the default Grid system and at the right side input your first node point coordinates as (X Y Z)=(0 0 0)

After than select the node by using node cursor >Geometry >Translational Repeat >Select Global Direction = X > No of Steps = 3 >now write down the column spacing from your Column Layout Plan as (Step1 =19.5, Step2 =8.5, Step3 =19.5) >Link Steps >OK.

After than select the total beam by using Beam cursor >Geometry >Translational Repeat >Select Global Direction = Z >No of Steps = 1 >now write down the column spacing from your Column Layout Plan as (Step1 =15.667 ft) >Link Steps >OK.

Now select the column node no 5 & 8 from the 2nd row >Geometry >Translational Repeat >Select Global Direction = Z > No of Steps =2 > now write down the column spacing from your Column Layout Plan as (Step1 =12.25, Step2 =11) \Box OK

Again select the column node no 9 & 10 by using node cursor >Geometry >Translational Repeat >Select Global Direction = X > No of Steps =3 >now write down the column spacing from your Column Layout Plan as (Step1 =13.25, Step2 =21, Step1 =13.25) >OK

Properties:	Load Definitions:
Column: C1= 12"X15"	1. Seismic Definition: (Dhaka zone)
C2=12"X18"	EQx & EQz
C3=12"X20"	Wind Definitions: (for Dhaka)
	Wx & Wz
Beam: GB = 10"X18"	*Wind speed for Dhaka zone = 210 km/hr = 130 mile/hr
FB = 10"X20"	3. Dead Load:
Varenda Beam: 6" X 6"	Self weight (Factor=1)
	Slab weight = 75 psf (For slab thickness= 6")
 All supports are fixed support 	Floor Finish (FF) = 30 psf
 Bottom story height = 8°-0" 	Partition wall load (PW) = 25 psf
 Typical story height = 10'-0" 	Wall load on beams (W) = 416 Ib/ft (for 5" brick wall)
 Top story for lift & stair = 8'-0" 	4. Live Load: LL = 40 psf
	Load Combinations:
	UFL = DL + LL
	FDL = 1.2*DL+1.6*LL
	FDLEQx = 0.9*DL+1.2*LL+1.32*EQx
	FDLEQz = 0.9*DL+1.2*LL+1.32*EQz
	FDLWx = 0.9*DL+1.2*LL+1.2*Wx
	FDLWz = 0.9*DL+1.2*LL+1.2*Wz

- For create beam layout: Go to Geometry >Add Beam >Add Beam from Point top Point and then connect the nodes points each other as the given Beam layout plan. Again for interesting beam go to Geometry >Add Beam >Add Beam by Perpendicular Intersection
- Veranda Create: Now select the node no 12 >Geometry >Trtranslational Repeat □ Select Global Direction = X> No of Steps =1 > now write down the Veranda length as (Step1 = -10.5) >OK
- Again select the beam from node no 12 to 19 by using beams cursor >Geometry >Translational Repeat >Select Global Direction = Z > No of Steps =1 >now write down the now write down the Veranda width as (Step1 =3) >Click on Link Steps >OK (Figure: 5.9). And similarly create another Veranda.
- Now Story Create: Select whole structure >Geometry >Translational Repeat
 >Select Global Direction = Y> No of Steps =8(7 stoy+1 is bottom story for base)>Default Step Spacing = 10(Typical story height) and Step1 = 8)
 >Click on Link Steps >OK

General (Define & Assign):

Support Create and Assign:

Click on View from +Z >Select the all bottom Story beams >Delete>Ok >Yes

From left side Click on General >Support >Create > Fixed >Add

Select S2 Support 2 >Select all bottom Nodes by using Node Cursor >Assign to Selected Nodes >Assign >Yes.

Result:

Pre-Viva Questions:

- 1. What is base velocity?
- 2. How many zones are there?
- 3. What is code for wind load?
- 4. How many types of models are in structure wizard?
- 5. How to apply wind load?

- 1. What is castigliano's theorem
- 2. What is formula for wind load calculation?
- 3. What is maxwell's theorem?
- 4. What is the unit for wind load?
- 5. What is storey height?

EXPERIMENT NO: 9

ANALYSIS AND DESIGN OF STEEL TRUSS

Aim: To analyze the Truss using STADD pro.

Software:

STADD pro software, compute,

PROCEDURE:

- 1. Entering Job information.
- 2. Truss model geometry
- 3. Defining member properties , sections
- 4. Assigning Loads(Load Cases and combination)
- 5. Defining Pre-Analysis Print out, analysis type and Post-Analysis print out
- 6. Defining Design Requirements

How to Start Staad Pro:

The Pic below shows how to start Staad Pro



In New File select

- 1. Truss
- 2. Units (here KN and mm in this example)

Add Beam Add Plate				
Add Solid Open Structure Wizard	6 I	12	A ANALY ANALY	
Copen STAAD Editor			12	
	_			
		Calls.		
•	<u> </u>			_
Provide information about I before building your model	the job (i.e. client's n	ame, job title, en	pineers involved, etc.)	<u>, 1</u>
Provide information about t before building your model	the job (i.e. client's n	ame, job title, en	jineers involved, etc.)	2
Provide information about before building your model	the job (Le. client's n	ame, job title, en	gineers involved, etc.)	
Provide information about before building your model	the job (i.e. client's n	ame, job title, en	jineers involved, etc.)	
Provide information about before building your model	the job (i.e. client's n	ame, job title, eny	prees involved, etc.)	
Provide information about to before building your model	the job (i.e. client's n	eme, job tille, en	jineers involved, etc.)	
Provide information about to before building your model	the job (i.e. client's n	eme, job tille, en	jineers involved, etc.)	

The staad Graphical interface will appear as shown in below picture



1. Entering Job Information

I leirotu T doL	12
Client Student	10
Job No. 1	14
Rev	
Part	
Ref	104
File	
Filename : Tutosial 1.std	
Directory : C:\Documents and	
Date / Time : 10-Jun-2008 08:49 PM	
File size : 106 More	
Engineer Decker Annuned	
Name Shah Alam	100
Date 10Jun 08	
Comment	
14	18
	1 20

Building Model (structure) Geometry

• Defining Truss Geometry

One of the methods that you can construction lines and then draw on these lines the truss

members

Noting that the no. of construction lines is excluding Ist line..





After clicking Snap Node/Beam ,use the mouse and connect between nodes created at the intersections of construction lines



How to see Diagram Labels (Nodes Numbers, Beam Numbers etc)





Node and beam labels are a way of identifying the entities we have drawn on the screen, and very useful when dealing with the output results

3. Defining member properties, sections



Property

In which we can define or choose sections properties of the members of the truss.

- Spec.: In which we can define or choose members' specifications.
- Support: In which we can define the supports properties (restraints).
- Load: In which we can define the applied loads, load cases, load combinations.
- Material In which we can define the material properties (ex. E, density, etc.)

Assume Preliminary

• Sections:

	Material	
Highlight Assig	ned Segnetry	
and address and		Delete
	EOL.	
Values	Edit Section Database	Define
Values Materials	Edt Section Dalabase Thickness_	Define User Table

All Top and Bot chords are one size L 55*55*3 All Diagonals and verticals are one size L 45 * 45* 3

A Anesicon Santa Sait A Anesicon State Sait A Anesicon Cold Formed Autotation Binkh C Gradian M W Shape M D Davrel M C Downed M	Select Angle Type Specification UB0500 # L200501 # L200502 # L200503 # L200504 # L200505 # <tr< th=""><th></th></tr<>	
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--

Assigning the sections created to the model

	Section Bala Angl	lo) Material	
	1 L45050 2 L55550	STEEL	
2 2.82 3 3.82 4 4.82 5	F Halidi Assor	ed Geometry	
1.01 6.01 12.01 10.01 13.01 11.01 5.0		ER.	Delete
	Values .	Sector Database	Define
1 B:R2 B 7:R2 7 6:R2 B	Materials .	Thickness.	Uses Table.
-	Assignment Hote Concernations Assign To Edit	od Hand Danma - 🖉 🕻 Gar - Ca	Ine Cursor To A Arrige To View

• Supports

By clicking on the support icon the shown window will appear. We have to create new kinds of supports

S1 No support	Enland But Multimer Song Faundation Vicined Faund Preed Faundation Enland	Hinged or Pinned suppor
Edit Create Delete	Restairt F PX F MX F FY F MY	Restraints (Fx, Fy, Fz)
Assignment Method C Assign To Selected Nodes C Assign To View C Use Dursor To Assign C Assign To Edit List	P R P 112	Y,

Helease	Daine Sping	
IF FX	1050	Miller
E PY	1.Fr	356/8m
P 12	1JZ	100mm
SE MC	KMC	Minavida
₩.Mr	son:	h31 mm/de
9 M2	MZ.	Ad-maxide

(Fixed but) Support

All directions are restrained or fixed and we choose what are the directions that we want to release. $Y \rightarrow Y \rightarrow Y$

Use the mouse and click on the nodes according to its support type as shown below

х



• 4. Defining Loads

The creation and assignment of load cases involves the following two steps:



- 1. First, we will be creating all 3-load cases.
- 2. Then, we will be assigning them to the respective members/nodes



For example

Dead Load Case can be Load Case No.1

Panag Load Generation Define Combinations Auto Load Combination	Primary			
	Number 1	Loading Type	None Rossie Live	
	Tale [Dead Load		Wind Sreanio Srow Ruda	
			A40	Dave Heb

Live Load Case can be Load Case No. 2 and Wind Load is the Case No.3

Primary Load Generation Datine Contensions Auto Load Contension	Primary				
	Harden 2	Loading Type	None Clead	<u>×</u>	
	Tille Uve Loads		Appl Live Wind Seime Show Flath		
			4		

Also, we can define **load combinations** according to required.

For example, we can create a load combination

1.25 D.L. + 1.5 L.L + 0.8 W.L.

CHEVE .		2113			
vbm aftern	Load No: 4	Nase COMBI	NATION LOAD CAS	E.A.	
Auto Lead Cambriation	Fype F Normal	General Format	a */		
	C SRSS	Constraint of the		A CONTRACTOR OF	
	C ABS	Column M.		Contraction of the second s	
	Autobal and Cares	Constant of the	Load Contribution (alation 197 - Alat	
	Wyasable Coab Calles		Load Cases	Fector	70C
		121	Losd Cese 5	a ₁ =1.25	
			Load Case 3	a, =0.0	
			-		
		321			
		<u></u>			
		23	-		

And In Dead Load Create the Self weight as



In each Load Case Create the Nodal Loads on truss as specified before. Make sure of the direction of forces according to global coordinates

Note Load Plate Plate Procession Annolised Procession Softer Load Softer Load Softer Load Softer Load Softer Load Softer Load Softer Load Softer Load Softer Load Softer Load Tenpostar Load Tage Thing Yind Load Report Load Report Load Tenpose Spectre Report Load Tenpose Spectre Report Load Tenpose Spectre	531 Ma 0 Streen 331 Map 0 Streen 335 Map 0 Streen
<u> </u>	AddHep
And a state of the	👔 🚺 Delminara
	Coad Caser Detain Coad Caser Coa



After Creating the commond of (Perform Analysis-Check);We have to assign the members that want to be this type of analysis for it.

Click Assign and then use the cursor and choose all the members, thus all the members should

be highlighted as shown below.



Pre-Print

To add the Pre-Print Commond click" Define Commands"



For example here we have choosen to print the support reactions, memberforces, joint

displacements



Post Print Commands

- Support reactions
- Analysis results

- Member Forces
- Max Forces

Add which property you need and then use cursor to ASSIGN to which member in the truss

Member Stresses Element	e Max Force	Story Drift Cg Mode Shapes	Surface Forces Element Stress Solid
Load List Section Support Reactions	Joint Di Analysis Result	splacement s Membe	Member Forces In Section Forces
This comman	d has no additional	parameters.	
THE SOUTHER			

6. Defining Design Requirements

Steps

1. To Specify steel design parameters, go to Design/Steel page from the left side of the screen. Make sure that under the Current Code selections on the top right hand side ,Canadian is selected.



There are many Design Commands in the STAAD Design subroutine. Here, we will use only to **Check Code**, regarding adequacy of members.



7-Analysis & Viewing Results

STAAD Performs Analysis and Design simultaneously. In order to Perform Analysis and Design, select the Run Analysis option from the Analyze menu



When you select the Run Analysis option from the Analyse menu, the following dialog box appears. We are presented with the choice of 2 engines. The **STAAD engine** and the STARDYNE Advanced **Analysis engine**. The **STARDYNE** Analysis engine is suitable for advanced problems such as **Buckling Analysis, ModaL Extraction** using various method ,etc **STAAD** engine is suitable for this tutorial. Click on th **Run Analysis** button.



The solving process is shown in pop up screen.

STAAD Analysis and Design	
++ Processing Element Stiffness Matrix. ++ Processing Global Stiffness Matrix	17:42:35
++ Finished Processing Global Stiffness Matrix.	0 sec
++ Processing Triangular Factorization	17:42:35
++ Finished Triangular Factorization.	0 sec
++ Calculating Joint Displacements.	17:42:37
++ Finished Joint Displacement Calculation.	0 sec
++ Calculating Member Forces	17:42:37
++ Analysis Successfully Completed ++	
++ Calculating Section Forces	
++ Performing Steel Design	12.42.22
++ Start Steel Design	0.000
++ creating Displacement File (DSP)	17-42-37
++ Creating Reaction File (REA)	111.046-01
++ Calculating Section Forces	
++ Creating Section Force File (EMD)	
++ Creating Section Displace File (SCN)	
++ Creating Design information File (DGN)	
++ Done.	17:42:39
0 Error(s), 0 Warning(s)	
as End STAID Pro Pro Flamend Tran a 5 Core	
A Cutent Unitten to File.	
Tutovial1 anl	
and the second se	
View Output File	
Gio to Post Processing Mode	- Frank - Frank
Stavin Modeling Mode	Done

Visualization of Some Results



Result:

Pre-Viva Questions:

- 1. What are the different types of strusses?
- 2. What is north light truss?
- 3. What is girder?
- 4. What is purlin?
- 5. What is the thickness of sheet?

- 1. What is the moment in pinjointed truss?
- 2. How are loads applied in the truss?
- 3. How to check whether the member is pass or not?
- 4. What type of loads are considered in truss?
- 5. Which is the major load in truss?

EXPERIMENT-10

ANALYSIS AND DESIGN OF ISOLATED FOOTING

Aim: To analyze and design isolated footing

HARDWARE & SOFTWARE REQUIRED:

Computer with specified configuration with installed Microsoft Office

Reinforced Concrete Footings:

<u>Footing</u> comprises of the lower end of a <u>column</u>, pillar or wall which i enlarged with projecting courses so as to distribute load.

Footings shall be designed to sustain the applied loads, moments and forces and the induced reactions and to ensure that any settlement which may occur shall be as uniform as possible and the safe bearing capacity of soil is not exceeded.

In sloped or stepped footings, the effective cross-section in compression shall be limited by the area above the neutral plane, and the angle of slope or depth and location of steps should be such that the design requirements are satisfied at every section.

Design Procedure of Column Footings | Foundation Design

Here is a step-by-step guide to Column Footing Design:



Step 1

Area required for footing Square = B = (w+w1)/P0Where, Po = safe bearing capacity of soil w1 = self weight of footing W = self weight of footing For Rectangle = b/d = B/DA = b x d Net upward pressure on the footing q/p = W/A

Step 2

Bending Moment Critical section for maximum <u>bending moment</u> is taken at the face of the column For a square footing, $M_{xx} = q \times B/8 (L - a)^2$ $M_{xx} = q \times L/8 (B - b)^2$ $M_{yy} = q \times B/8 (L - a)^2$

Step 3

To fix the depth of the footing shall be greater of the following: Depth from bending moment consideration $d = \sqrt{M/Qb}$ where, Q = moment of required factor Depth from shear consideration Check for one way shear Check for two way shear or punching shear Critical shear for one way shear is considered at a distance 'd' from face of the column. Shear force, $V = qB[\frac{1}{2}(B-b)d]$ Nominal shear stress, $T_v = k \cdot T_c$ $T_c = 0.16 \sqrt{fck}$ Step 4 Check for two way shear Critical section for two way shear is considered at a distance at a distance d/2 from all the faces of the column. SF, V = q $[B^2 - (b + d)^2]$ SF, V = q [L x B - (a + d)(b + d)] Nominal shear stress, $T_v = V/2((a+d)(b+d)d)$ ——- {for a rectangle $T_v = k \cdot T_c$ $k = 0.5 + \beta > 1$; [Beta β = ratio of sides of the column $T_c = 0.16\sqrt{fck}$ Area of steel, $Ast = M/((\sigma)stid)$

ISOLATED FOOTING WITH BIAXIAL MOMENT

CALCULATION FOR BOTTOM STEEL

Hence, Ast =

pt required = provide a maximum :

Spacing required =

Spacing provided = pt provided =

Min Ast =



90.27 KN-m per meter Mulimit = 450.81 KN-m per meter The section is singly reinforced

(0.12 % for slab, cl 26.5.2.1) (considering max of above two calculated values of Ast)

Hence provide 12 mm dia bar @ 150 mm c/c parellel to length of footing (|| to Z)

640.194 mm²

484.800 mm²

176.66 mm

0.19 % 0.16 %

0.19 %

150 mm

Mu about N1 N1 = (;	pe max_x_length ² /2)=	93.30 KN-m per meter
Calc. Ast =	662.496 mm ²	The section is singly reinforced
Min Ast =	484.8 mm ²	(0.12 % for slab, cl 26.5.2.1)
Spacing =	170.71 mm	(considering max of above two calculated values of Ast)
Spacing provided =	150 mm	
pt provided =	0.19 %	
pt required =	0.16 %	
provide a maximum :	0.19 %	
Hence provide 12 mr	n dia bar @ 150 mm c/c pa	arellel to breadth of footing (to X)
Arrangement of bot	tom reinforcement as per	above design is shown below



CHECK FOR ONE WAY SHEAR : One way shear at critical section Distance of critical sec. from edge of Shear force Vs =pe max x 0.196 x Shear stress $\tau_v = Vs/bd =$ $\tau_c = 0.32$ tv < tc hence O.K.	L1- L1 of footing = 1m width of footing = 0.243 N/mm ² N/mm ²	0.196 m 98.289 KN
One way shear at critical section Distance of critical sec. from edge of Shear force Vs =pe max x 0.206 x Shear stress $\tau_v = Vs/bd =$ $\tau_c = 0.32$	L2- L2 of footing = 1m width of footing = 0.256 N/mm ² N/mm ²	0.206 m 103.304 KN
tv < tc hence O.K.		
CHECK FOR TWO WAY SHEAR Ref. cl 34.2.4 and cl.31.6.3 of IS 45 Allowable shear stress $\tau_{\rm v allowable}$ =	6 : 2000 k _s $ au_{ m c}$	
k _s = (0.5 + b/c) =	1.011111111 >1	
Hence, k₅=	1	
$\tau_{c} = 0.25 \text{ (fck)}^{0.5} =$	1.118033989 N/mm ²	
$\tau_{v \text{ allowable}}$ = k _s x τ_{c} =	1.118033989 N/mm ²	
Shear force Vs = 501.476 (1.65 x	1.45 - 0.854 x 0.634) =	928.26 KN
Length of critical section = 2 x (854	+ 634) =	2976 mm
Area of the critical section (length of Hence shear stress $\tau_v =$	0.772 N/mm ²	1202304 mm ⁻

tv < allowable hence O.K.

1	Footing Size Design			
	Load Design Load	Pu P	1500 KN 1100 KN	
	Moment in x dir Moment in y dir	Mux Muy	30 KN-m 30 KN-m	
	Column size	cx cy	450 mm 450 mm	
	SBC	q	150 KN/sqm	
	Footing Size required	A req	7.33 sqmm	
	Footing Size Provided Area Provided	L B A prvd	3.30 meters 2.40 meters 7.92 meters	
		Zx Zx	3.17 4.36	
	Net upward pressure	Nup	150 KNm2	
		Foot	ing Size OK	



Result:

Pre-Viva Questions:

- 1. What are the different types of footing?
- 2. What is isolated footing?
- 3. What bearing capacity?
- 4. How to calculate bearing capacity?
- 5. What are different types of soils?

- 1. What is concrete cover to footing?
- 2. What is cover for columns?
- 3. What is one way shear?
- 4. What is two way shear?
- 5. For which soil bearing capacity is more?

EXPERIMENT NO: 11

ANALYSIS AND DESIGN OF COMBINEDFOOTING

Aim:

To analyze and design the combined Footing using STADD pro

HARDWARE & SOFTWARE REQUIRED:

Computer with specified configuration with installed STADD Pro Software.

Procedure:

- 1. Entering Job information.
- 2. Truss model geometry.
- 3. Defining member properties , sections.
- 4. Assigning Loads(Load Cases and combination).
- 5. Defining Pre-Analysis Print out, analysis type and Post-Analysis print out.
- 6. Defining Design Requirements.
- 7. The combination of STAAD.pro and STAAD.beava can make your bridge design and analysis
- 8. easier. STAAD.pro is first used to construct the bridge geometry and STAAD.beava is used to
- 9. find the AASHTO 2002 load positions that will create the maximum load response. The
- 10. maximum load response could be any of the following:
- 11. 1. Maximum plate stresses, moment about the local x axis of a plate (Mx), moment about
- 12. the local y axis of a plate (My) etc. used to design for concrete deck reinforcement.
- 13.2. Maximum support reactions to design isolated, pile cap, and mat foundations.
- Maximum bending moment or axial force in a member used to design members as per
- 15. the AASHTO code.
- 16. 4. Maximum deflection at mid span.
- These loads that create the maximum load responses can be transferred into STAAD.pro as load

18. cases to load combinations for further analysis and design. Figure 1 shows

the bridge design

19. procedure discussed above.

Step 1

Area required for footing Square = B = (w+w1)/P0Where, Po = safe bearing capacity of soil w1 = self weight of footing w = self weight of footing For Rectangle = b/d = B/D A = b x d Net upward pressure on the footing q/p = W/A

Step 2

Bending Moment Critical section for maximum <u>bending moment</u> is taken at the face of the column For a square footing, $M_{xx} = q \times B/8 (L - a)^2$ $M_{xx} = q \times L/8 (B - b)^2$ $M_{yy} = q \times B/8 (L - a)^2$

Step 3

To fix the depth of the footing shall be greater of the following: Depth from bending moment consideration $d = \sqrt{M/Qb}$ where, Q = moment of required factor Depth from shear consideration Check for one way shear Check for two way shear or punching shear Critical shear for one way shear is considered at a distance 'd' from face of the column. Shear force, $V = qB[\frac{1}{2}(B-b)d]$ Nominal shear stress, $T_v = k \cdot T_c$ $T_c = 0.16\sqrt{fck}$ Step 4 Check for two way shear Critical section for two way shear is considered at a distance at a distance d/2 from all the faces of the column. SF, V = q $[B^2 - (b + d)^2]$ SF, V = q [L x B – (a + d)(b + d)] Nominal shear stress, $T_v = V/2((a+d)(b+d)d)$ ——- {for a rectangle

Analysis is done as explained in combined footing

Result:

Pre-Viva Questions:

- 1. Why is combined footing used?
- 2. What are different types of combined footings?
- 3. How to improve the soil conditions?
- 4. What is the cover for combined footing?
- 5. What is the diameter used footing?

- 1. What is two way shear in combined footing?
- 2. On what basis depth of footing calculated?
- 3. What is net bearing pressure on footing?
- 4. How is the depth of footing calculated?
- 5. What in one way shear in combined footing?
EXPERIMENT NO: 12

ANALYSIS OF BRIDGE DECK SLAB

AIM: To analyze the Bridge Deck Slab using STADD pro

HARDWARE & SOFTWARE REQUIRED:

Computer with specified configuration with installed STADD Pro Software.

PROCUDURE AND ANALYSIS STEPS

The combination of STAAD.pro and STAAD.beava can make your bridge design and analysis easier. STAAD.pro is first used to construct the bridge geometry and STAAD. beava is used to find the AASHTO 2002 load positions that will create the maximum load response. The maximum load response could be any of the following:

1. Maximum plate stresses, moment about the local x axis of a plate (Mx), moment about the local y axis of a plate (My) etc. used to design for concrete deck reinforcement.

2. Maximum support reactions to design isolated, pile cap, and mat foundations.

3. Maximum bending moment or axial force in a member used to design members as per the AASHTO code.

4. Maximum deflection at mid span.

These loads that create the maximum load responses can be transferred into STAAD.pro as load cases to load combinations for further analysis and design. Figure 1 shows the bridge design procedure discussed above.



Figure 1: Bridge Design process in STAAD.pro

Creating the Bridge Geometry/Structural Analysis

Figure 2 shows a bridge with the dimensions.



Figure 2: Bridge Dimensions

Step By Step Procedure

1. Open STAAD.pro with the default units of Kip-Ft and use the Space option.

2. Click the Next button and select the Add Beam mode. Click Finish.

3. The goal of the next few steps is to draw the stick model of the Bridge Structure (i.e. the beams and the girders). Select the X-Z grid option. Create two grid lines in the x direction at 80ft spacing. Create four grid lines in the z direction at 10ft spacing.

4. Click on the Snap Node/Beam button and draw the beams and the girders as shown below. First draw five 160ft girders. Then draw the 40ft beams in the z direction.

5. Click on Geometry->Intersect Selected Members->Highlight. STAAD.pro will highlight all the beams that intersect each other no common nodes. To break these beams at the intersection point, click on Geometry->Intersect Selected Members->Intersect

6. The beams have been created. The columns will now be created using the translational repeat command. Select nodes 6, 14, and 7 using the nodes cursor as shown below. The node numbers may vary depending upon how the model was constructed. Select Geometry->Translational Repeat from the menu. Select the y direction for the translational repeat and select enter a Default Step Spacing of -25ft

7. The deck of this bridge structure will be created in the following steps using the Generate Surface Meshing Tool. In reality, spacing of beams etc. may not be regular and hence it may become difficult to create the deck of the bridge using the Generate Surface Meshing Tool. The Parametric Meshing Mode could become very useful in these circumstances.

8. Select the Geometry->Generate Surface Meshing tool from the menu. Select four nodes that outline the 160ft x 40ft deck. Simply click on node 1, 3, 11, and 10 and select node 1 again to complete the command. Select the Quadrilateral Meshing option.

9. 2ft x 2ft element size is adequate for this type of model. Hence input the parameters as shown below.

10. The mesh will be created. To view the mesh properly, you will need to click on the Setup Control Tab on your left.

11. You should note that the girders and beams are automatically broken down into smaller elements. In reality, the girders are physically attached to the deck hence it is ok to mesh them. The concrete beams parallel to the z-axis are not attached to the deck. The load from the deck is transferred to the 40ft steel girders. The load from the girders is then transferred to the concrete beams. Hence, we should merge the beams in the z direction. Select the Select->Beam Parallel To->z from the menu.

12. Select Geometry->Merge Selected Members to merge the split concrete beams. Select each entry and press the Merge button.

13. By merging the beams together, the concrete column to beam connectivity is lost. Hence, click on Geometry->Intersect Selected Members->Highlight. STAAD.pro will highlight all the beams that intersect each other no common nodes. To break these beams at the intersection point, click on Geometry->Intersect Selected Members- >Intersect.

Concrete Deck	Plate elements - 12in thick
	Material - Concrete
Steel Girders – Parallel to x axis	40ft Beam elements – W24X103
	Material – Steel
	Offset = 0.5 x Depth of Beam + 0.5 thickness of slab
	= 0.5 x 2.044167 ft + 0.5 x 1ft = 1.5220835 ft at both
	ends.
Concrete Beam – Parallel to the z	2ft x 2ft Sections
axis	Material – Concrete
	Offset = 0.5 x Depth of Concrete Beam + Depth of
	Steel Beam + 0.5 thickness of slab = 0.5 x 2ft +
	2.044167 ft + 0.5 x 1ft = 3.544167 ft at both ends.
Concrete Columns	2ft Circular Sections
	Material – Concrete
	Offset = Depth of Concrete Beam + Depth of Steel
	Beam + 0.5 thickness of slab = 2ft + 2.044167 ft + 0.5
	x 1ft = 4.544167ft at the end connected to the
	concrete beams.

15. Click on the General->Property control tab on your left and click on the Section Database button.

16. Select the W24x103 section from the American W shape database and click on the Add button.

17. Select the W24x103 section that has been created. Click on the Select the Select->Beam Parallel To->X from the menu and click on the Assign button on the right.

18. Select the Define button on the right and select the Circle section profile. Input a 2ft diameter and press the Add button.

19. Select the Rectangle section profile and input 2ft in the YD and ZD input boxes. Press the Add button. Press the Close button.

20. Select the Cir 24 section that has been created. Click on the Select the Select->Beam Parallel To->Y from the menu and click on the Assign button on the right.

21. Select the Rect 24.00x24.00 section that has been created. Click on the Select the Select->Beam Parallel To->Z from the menu and click on the Assign button on the right.

22. Press the Thickness button the right and input 1ft in the Node 1 input box and press the Add button.

23. Select the newly create Plate Thickness entry in the Properties dialog box. Select all the plates using the Plates Cursor and press the Assign button.

24. Select the Spec sub-control tab on the left.

25. Press the Beam button. Select the Offset tab. Select the start option from the location selection box. Select the local option from the Direction selection box. Input an offset of - 1.5220835 in the Y input box. Press the Add button.

26. Press the Beam button. Select the Offset tab. Select the End option from the Location selection box. Select the Local option from the Direction selection box. Input an offset of - 1.5220835 in the Y input box. Press the Add button.

27. Assign these specifications to the steel girders parallel to the x-axis. Select the START LOCAL 0 - 1.52208 0 specification that has been created. Click on the Select->Beam Parallel To->x from the menu and click on the Assign button on the right.

28. Select the END LOCAL 0 -1.52208 0 specification that has been created. Click on the Select the Select->Beam Parallel To->x from the menu and click on the Assign button on the right.

29. Repeat Steps# 25 to 28 for the concrete beams but use a y-offset of -3.544167 ft at both ends. For Step# 28, you will need to select beams parallel to the z-axis.

30. For the columns assign a local x-offset of 4.544167ft at the end connected to the concrete beams.

31. Click on the View->3D Renderingin the menu.

32. Select the General->Support tab on the left and click on the Create button in the right hand side Data Area. Click on the Add button (i.e create a fixed support entry).

33. Select the newly created S2 Support 2 entry and using the nodes cursor select nodes 16,17, and 18. Click on the Assign button.

34. Select the General->Load tab on the left and click on Load Case Details on the right hand side in the Data Area.

35. Click on the Add button on the right. Input the "Dead Load" in the Title input box. Select "Dead" in the Loading type selection box. Press the Add button. Click the Close button.

36. Select the newly created 1: Dead Load entry in the data area. Press the Add button. Select the Self-weightitem and press the Add button.

37. Click on the Analysis/Print control tab item on the left and press the Add button.

38. Click on the Analyze->Run Analysis menu. Use the STAAD Analysis option and click on the Run Analysis button.

39. If the analysis completed successfully, you should look at the exaggerated deflected shape of the bridge under the action of selfweight. Try to find out any connectivity problems etc. You can go to the Post-Processing mode by clicking on Mode- >Postprocessingcommand in the menu.

40. You can look at the bending moment diagram for the bridge by clicking on the Beam->Forces control tab on your left in the Post-Processing mode.

41. You can look at the stress distribution diagram for the bridge by clicking on the Plate control tab on your left. Select the Max Absolute stress type from the Stress Type selection box and click on the Ok button.

Result:

Pre-Viva Questions:

- 1. What is deck slab?
- 2. Explain different types of bridges?
- 3. On what what basis design loads are considered?
- 4. What is load combination used in bridges?
- 5. What is code for bridges?

Post Viva Questions:

- 1. What is mix proportion used in bidges?
- 2. What types of loads are considered?
- 3. Why are moving loads considered?
- 4. What is truck load?
- 5. What is the full form of IRC?