EMBEDDED PROGRAMMING LABORATORY

LAB MANUAL

Course Code	:	BESB09
Regulations	:	IARE - R18
Class	:	I Semester
Branch	:	M.TECH(ES)

Prepared By

Ms. M. SUGUNA SRI Assistant Professor, ECE



Department of Electronics & Communication Engineering INSTITUTE OF AERONAUTICAL ENGINEERING

(Autonomous) Dundigal – 500 043, Hyderabad

INDEX

S. No	Name of the Content	PAGE NO.
1	Lab Objective	3
2	Introduction About Lab	4
3	LAB CODE	5
4	List of Lab Exercises	6
5	Description about ES Concepts	7
6	Programs List	13
7	References	82

Lab Objective:

An embedded system is some combination of computer hardware and software, either fixed in capability or programmable, that is specifically designed for a particular kind of application device. Industrial machines, automobiles, medical equipment, cameras, household appliances, airplanes, vending machines, and toys (as well as the more obvious cellular phone and PDA) are among the myriad possible hosts of an embedded system. Embedded systems that are programmable are provided with a programming interface, and embedded systems programming is a specialized occupation.

An **embedded system** is a special-purpose computer system designed to perform one or a few dedicated functions, often with real-time computing constraints. It is usually *embedded* as part of a complete device including hardware and mechanical parts. In contrast, a general-purpose computer, such as a personal computer, can do many different tasks depending on programming. Embedded systems have become very important today as they control many of the common devices we use.

Since the embedded system is dedicated to specific tasks, design engineers can optimize it, reducing the size and cost of the product, or increasing the reliability and performance. Some embedded systems are mass-produced, benefiting from economies of scale.

INTRODUCTION ABOUT LAB

There are 30 systems (Dell) installed in this Lab. Their configurations are as follows:

Processor	:	Intel(R) core (TM) - i3 -4150
CPU RAM	:	4 GB
Hard Disk	:	500 GB
Mouse	:	Optical Mouse
Network Interface card	:	Present

Software

- 1 All systems are configured in DUAL BOOT mode i.e, Students can boot from Windows 07. This is very useful for students because they are familiar with different Operating Systems so that they can execute their programs in different programming environments.
- 2 Each student has a separate login for database access
- 3 Software installed: Keil Micro vision, OFFICE-07, Systems are provided for students in the1:1 ratio.
- 4 Systems are assigned numbers and same system is allotted for students when they do the lab.

LAB CODE

- 1. Students should report to the concerned labs as per time table schedule.
- 2. Students who turn up late to the labs will in no case be permitted to do the program scheduled for the day.
- 3. After completion of the program, certification of the concerned staff in-charge in the observation book is necessary.
- 4. Students should bring a notebook of about 100 pages and should enter the reading/observations into
- 5. the notebook while performing the experiment.
- 6. The record of observations along with the detailed experimental procedure of the experiment performed in the immediate last session should be submitted and certified by the staff member in-charge.
- 7. Not more than three students in a group are permitted to perform the experiment on a setup.
- 8. The group-wise division made in the beginning should be adhered to and no mix up student among different groups will be permitted later.
- 9. The components required pertaining to the experiment should be collected from stores in-charge after duly filling in the requisition form.
- 10. When the experiment is completed, students should disconnect the setup made by them, and should return all the components/instruments taken for the purpose.
- 11. Any damage of the equipment or burn-out of components will be viewed seriously either by putting penalty or by dismissing the total group of students from the lab for the semester/year.
- 12. Students should be present in the labs for the total scheduled duration.
- 13. Students are required to prepare thoroughly to perform the experiment before coming to Laboratory.
- 14. Procedure sheets/data sheets provided to the student's groups should be maintained neatly and to be returned after the experiment.

List of Lab Excercises

$\label{eq:constraint} \textbf{EMBEDDED PROGRAMMING LABORATORY} - \textbf{Lab Programs List}$

Submission -1

Week – 1	Program to toggle all the bits of port P1 continuously with 250 ms delay.
Week-2	Program to interface a switch and a buzzer to two different pins of a port such that the buzzer should sound as long as the switch is pressed.
Week-3	Program to interface LCD data pins to port P1 and display a message on it
Week-4	Program to interface seven segment display using 89V51RD2
Week – 5	Program to interface keypad. Whenever a key is pressed, it should be displayed on LCD
Week – 6	Program to transmit message from microcontroller to PC serially using RS232 Program to receive a message from PC to microcontroller serially using RS232
Week – 7	Program to interface Stepper Motor to rotate the motor in clockwise and anticlockwise Directions
Week – 8	Program to read data from temperature sensor and display the temperature value
Week – 9	Port RTOS on to 89V51 Microcontroller and verify. Run 2 to 3 tasks simultaneously on 89V51 SDK. Use LCD interface, LED interface, Serial communication.
Week – 10	Program to convert analog signal into digital (ADC).
Week – 11	Program to convert Digital into Analog (DAC).
Week – 12	Program to interface Elevator.

Description about ES Concepts:

Embedded systems are designed to do some specific task, rather than be a general-purpose computer for multiple tasks. Some also have real-time performance constraints that must be met, for reason such as safety and usability; others may have low or no performance requirements, allowing the system hardware to be simplified to reduce costs. Embedded systems are not always separate devices. Most often they are physically built-in to the devices they control.

The software written for embedded systems is often called firmware, and is stored in read-only memory or Flash memory chips rather than a disk drive. It often runs with limited computer hardware resources: small or no keyboard, screen, and little memory. Embedded systems range from no user interface at all — dedicated only to one task — to full user interfaces similar to desktop operating systems in devices such as PDAs. Simple embedded devices use buttons, LEDs, and small character- or digit-only displays, often with a simple menu system.

Embedded Systems components:



Introduction to 8051 Microcontroller:

- Microcontroller is a device which integrates number of components of a microprocessor system onto a single chip. It typically includes:-
- CPU (Central Processing unit)
- ► RAM & ROM
- ➢ I/O inputs & outputs − Serial & Parallel
- ➤ Timers
- Interrupt Controller

By including the features that are specific to the task (Control), Cost is relatively low. Microcontroller are a "one chip solutions" which drastically reduces parts count and design costs.

Block Diagram:



8051 Basic Components:

- ➢ 4K bytes internal ROM
- ➢ 128 bytes internal RAM
- Four 8-bit I/O ports (P0 P3).
- ➢ Two 16-bit timers/counters
- One serial interface

8051 features:

- ➢ 4K bytes ROM
- > 128 bytes RAM
- Four 8-bit I/O ports
- Two 16-bit timers
- Serial interface
- ➢ 64K external code memory space
- > ALU
- Working Registers
- Clock Circuits
- Timers and Counters
- Serial Data Communication.

8051 CPU Registers:

- ➢ A (8-bit Accumulator)
- ➢ B (8-bit register for Mul &Div)
- PSW (8-bit Program Status Word)
- SP (8-bit Stack Pointer)
- PC (16-bit Program Counter)
- DPTR (16-bit Data Pointer)

Pin Description of the 8051:



- > The 8051 is a 40 pin device, but out of these 40 pins, 32 are used for I/O
- 24 of these are dual purpose, i.e. they can operate as I/O or a control line or as part of address or date bus.

8051 Development Board (P89V51RD2)

On board Peripherals:

hex-key pad
 serial peripheral interface (spi)
 analog to digital converter
 digital to analog converter
 eeprom (i2c)
 lcd display
 lcd contrast (potentiometer)
 crystal oscillator
 serial port connector
 buzzer
 push button switches
 ps/2 connector
 power supply slide switch
 7805 voltage regulator
 relay

2) seven segment display
 4) led' display
 6) lm35 temperature sensor
 8) rtc battery
 10) rtc
 12) gnd and vcc
 14) p89v51rd2
 16) max232
 18) stepper motor driver
 20) reset button
 22) slide switches
 24) relay output connector
 26) power jack
 28) bridge rectifier

Overview:

The UTS-MC-KIT-M7.3 has got P89V51RD2 microcontroller which has got 64KiloBytes of on chip Flash memory and 1 KiloBytes of RAM. The kit is has got on board 11.0592MHz crystal for generating the on chip clock of 11.0592MHz.

A Key feature of the board is it has got so many interfaces, with different on board peripherals and has got expansion capability to add any further sensor and peripherals in future. This prototype board is very easy to use for 8051 architecture. This board is interfaced with LED's, 7 SEG display, LCD display, Pushbutton. This Board can also be interfaced with PC via serial communication and can be viewed through hyper terminal. The LCD display can be connected easily through connectors. No soldering work /No lose contact/ just plug in the berg connectors.

The board has got on chip peripherals like on board 32 KB bytes of RAM, Eight Light Emitting Diodes, four Push Buttons, Four Seven Segment Displays, 16X2 Liquid Crystal Character Display(LCD), Analog to Digital Converter, LM35 Temperature sensor, SPI based ADC, Hex Keypad, Buzzer relay, steeper motor driver interface, Real time clock, RS-232 serial interface.

Component Description: Microcontroller

The P89V51RD2 device contains a non-volatile 64KB Flash program memory.

In-System Programming (ISP) allows the user to download new code while the microcontroller sits in the application. A default serial loader (boot loader) program in ROM allows serial In-System programming of the Flash memory via the UART without the need for a loader in the Flash code.

This device executes one machine cycle in 6 clock cycles, hence providing twice the speed of a conventional 80C51. An OTP configuration bit lets the user select conventional 12 clock timing if desired.

This device is a Single-Chip 8-Bit Micro controller manufactured in advanced CMOS process and is a derivative of the 80C51 micro controller family. The instruction set is 100% compatible with the 80C51 instruction set.

The device also has four 8-bit I/O ports, three 16-bit timer/event counters, a multisource, and four-priority-level, nested interrupt structure, an enhanced UART and on-chip oscillator and timing circuits.

The added features of the P89V51RD2 makes it a powerful micro controller for applications that require pulse width modulation, high-speed I/O and up/down counting capabilities such as motor control.

Experimental Procedure for Keil4 IDE

(For all the experiments this procedure is same)

The RVision IDE is, for most developers, the easiest way to create embedded system programs. This chapter describes commonly used RVision features and explains how to use them.

RVision is a Windows application that encapsulates the Keil microcontroller development tools as well as several third-party utilities. RVision provides everything you need to start creating embedded programs quickly. RVision includes an advanced editor, project manager, and make utility, which work together to ease your development efforts, decreases the learning curve, and helps you to get started with creating embedded applications quickly.

There are several tasks involved in creating a new embedded project:

- Creating a Project File
- Using the Project Windows
- Creating Source Files
- Adding Source Files to the Project
- Using Targets, Groups, and Files
- Setting Target Options, Groups Options, and File Options
- Configuring the Startup Code
- Building the Project
- ➢ Creating a HEX File

The below section provides a step-by-step tutorial that shows you how to create an embedded project using the RVision IDE.

Downloading the hex file to the target using Flash magic Software:

Open the Flash Magic tool for downloading into the Microcontroller Board. Click on Device menu select option you will be popped up with a window named choose device. Under choose device options select 8051 and click on Ok button to open flash magic tool to download the hex file in to the MC

Terminal Software for Check the Serial port Data receiving from Microcontroller to PC:

Terminal is a simple serial port (COM) terminal emulation program. It can be used for communication with different devices such as modems, routers, embedded microcontroller systems, GSM phones, GPS modules... It is very useful debugging tool for serial communication applications.

EXPERIMENT – 1

Aim:

Write a Embedded C Program to toggle all the bits of Port P1 continuously with 250 mS delay led blink with 89V51RD2 microcontroller board

Equipment Requirements:

a) Hardware Requirements :

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

b) Software Requirements:

- 1. Flash Magic tool.
- 2. Keil evaluation software

LEDs Interfacing with 8051:



Source code:

/* Program to toggle all the bits of Port P1 continuously with 250 mS delay. */

#include<REG51.H>

```
#define LEDPORT P1
```

```
void delay(unsigned int); void
main(void)
{
LEDPORT =0x00;
while(1)
{
LEDPORT = 0X00;
delay(250); LEDPORT = 0x11;
delay(250);
}
}
void delay(unsigned int itime)
{
unsigned int i,j;
for(i=0;i<itime;i++)
{
for(j=0;j<250;j++);
}
}
```

Flow Chart:



Hardware configuration:

- Connect an 8 pin bus from Port 1 (P1) to the LED pins (No 3 pin strip) or place an 8 pin Jumper connecting No2 and No3 pin strips.
- > Turn Off and On the Board or just reset it to view the output.

Results/Output verification:

Now the led program is running on Microcontroller. And the output can be seen in the board. You can see led toggling





- 25 -

EXPERIMENT – 2

Aim:

Write a Embedded C Program to interface a switch and a buzzer to two different pins of a port such that the buzzer should sound as long as the switch is pressed.

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Rquirements :

- 1. Keil evaluation software
- 2. Flash Magic tool.

Interfacing Switch & Buzzer with 8051:



Source code:

/*Program to interface a switch and a buzzer to two different pins of a Port such that the buzzer

should sound as long as the switch is pressed.*/

```
sbit SW1 = P1^4;
sbit BUZZER = P3^6;
```

```
void main (void)
{
    BUZZER = 0;
    while(1)
    {
        if(SW1 == 0)
            {
            BUZZER = 1;
        }
        else
        BUZZER = 0;
    }
}
```

Flow Chart:



Hardware configuration:

- 1. Connect a single pin wire from PORT 1.4 to any switch available on board.
- 2. Place the jumper at jp6 jumper position to connect the buzzer onboard to the controller.
- 3. Turn ON and OFF or reset the board, to view the output.

Results/Output verification:

After programming the code into the microcontroller just reset the microcontroller. You can listen to the buzzer buzzing.



EXPERIMENT – 3

Aim:

Write a Embedded C Program to interface LCD data pins to port P1 and display a message on it using 89V51RD2

Equipment Requirements: Hardware Requirements :

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements :

- 1. Keil evaluation software
- 2. Flash Magic tool.

Interfacing 16*2 LCD with 8051:



Source code:

/*Program to interface LCD data pins to port P1 and display a message on it.*/

```
#include <reg51.h>
#include "lcd.h" // refer LCD.H code for more to about LCD
```

```
void Delay_sec(unsigned char s);
```

```
main()
ł
  LCD_init();
 while(1)
  {
    LCD_clear();
    Delay_sec(1);
    LCD_row1();
    LCD_puts(" welcome come to embedded lab ");
    LCD_row2();
    LCD_puts(" iare ");
    Delay_sec(5);
    LCD clear();
    Delay_sec(1);
    LCD clear();
    LCD_row1();
    LCD_puts("EMEBEDDED SYSTEMS ");
    LCD_row2();
    LCD_puts("AERONAUTICALENGG.");
    Delay_sec(5);
  }
}
void Delay_sec(unsigned char s)
ł
 unsigned char n;
 for (n=0; n<s; n++)
  {
    LCD_delay(250);
    LCD_delay(250);
 }
}
```

Hardware configuration and Realization:

- 1. Connect a 6 pin jumper or 6 pin bus from PORT 2 to LCD module available on board.
- 2. Turn ON and OFF or reset the board, to view the output.



Results/Output verification:

After programming the code into the microcontroller just reset the microcontroller. You can see the text on the LCD.



EXPERIMENT – 4

Aim:

Write a Embedded C Program to interface seven segment display using 89V51RD2

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements :

- 1. Keil evaluation software
- 2. Flash Magic tool.

INTERFCAING SEVEN SEGMENT DISPLAY WITH 8051:



Source code:

/*Program to interface seven segment display unit.*/ #include <REG51.H> #include <stdio.h>

#define LEDPORT P0

sbit CTRL0 = P1^0; sbit CTRL1 = P1^1; sbit CTRL2 = P1^2; sbit CTRL3 = P1^3;

#define	ZERO)	0x02
#define	ONE	0x9E	
#define	TWO	0x24	
#define	THREE	0x0C	
#define	FOUR	0x98	
#define	FIVE	0x48	
#define	SIX	0x40	
#define	SEVEN	0x1E	
#define	EIGHT	0x00	
#define	NINE	0x18	
#define	TEN	0x10	
#define	ELEVEN	0xC0	
#define	TWELVE	0x62	
#define	THIR	ΓEEN	0x84
#define	FOUR	TEEN	0x60
#define	FIFTE	EEN	0x70

```
void Delay(void);
```

void main (void)

{

```
CTRL0 = 1;

CTRL1 = 1;

CTRL2 = 1;

CTRL3 = 1;

while(1)

{

LEDPORT = ZERO;

Delay();

LEDPORT = ONE;

Delay();

LEDPORT = TWO;

Delay();
```

```
LEDPORT = THREE;
       Delay();
       LEDPORT = FOUR;
       Delay();
       LEDPORT = FIVE;
       Delay();
       LEDPORT = SIX;
       Delay();
       LEDPORT = SEVEN;
       Delay();
       LEDPORT = EIGHT;
       Delay();
       LEDPORT = NINE;
       Delay();
             LEDPORT = TEN;
       Delay();
       LEDPORT = ELEVEN;
       Delay();
       LEDPORT = TWELVE;
       Delay();
       LEDPORT = THIRTEEN;
       Delay();
       LEDPORT = FOURTEEN;
       Delay();
       LEDPORT = FIFTEEN;
       Delay();
 }
}
void Delay(void)
{
 int j;
 int i;
 for(i=0;i<30;i++)
 {
       for(j=0;j<10000;j++)
       {
       }
 }
}
```

HARWARE CONFIGURATION:

To check the output connects the wires as shown and press any key from the keypad that value should be displayed on seven segments.



Result:

Output shown on the seven segment display

EXPERIMENT – 5

Aim:

Write a Embedded C Program to 4*4 interface keyboard. Whenever a key is pressed, it should be displayed on LCD using 89V51RD2

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements:

- 1. Keil evaluation software
- 2. Flash Magic tool.

4*4 Matrix keyboard interfacing with 8051:



Source code:

/*Program to interface keypad. Whenever a key is pressed, it should be displayed on LCD.*/

```
#include <reg51.h>
#include"lcd.h"
sbit C1 = P1^0;
sbit C2 = P1^{1};
sbit C3 = P1^{2};
sbit C4 = P1^{3};
sbit R1 = P1^{4};
sbit R2 = P1^{5};
sbit R3 = P1^{6};
sbit R4 = P1^{7};
unsigned char key;
void Delay(unsigned int);
void delay()
{
  unsigned int i;
                                               /* For 1 ms */
 for (i=0; i<10; i++);
}
unsigned char READ_SWITCHES (void)
                                                      // initialize the port for inputs
Ł
         // P1.0 to p1.3 are outpot; and P1.4 to P1.7 are inputs
 // the keybad is connected to port 1
 // make all rows = 1
  R4=1;
 R3=1;
 R2=1;
 R1=0;
  //test row 1
 if (C1 == 0)
                  // key 1 is presed
  {
     delay();
                                //debounce
         while (C1==0);
                                               //wait until release the key
         return 1;
  }
 if (C2 == 0)
                                               //key 2 is pressed
  {
    delay();
                                        //debounce
         while (C2==0);
                                        //wait until release the key
                                               - 37 -
```

```
return 2;
}
if (C3 == 0)
                                              //key 3 is pressed
{
                                             //debounce
   delay();
  while (C3==0);
                                      //wait until release the key
       return 3;
}
if (C4 == 0)
                                               //key 4 is pressed
{
       delay();
                                      //debounce
                                       //wait until release the key
       while (C4==0);
  return 4;
}
//test row 2
R4=1;
R3=1;
R2=0;
R1=1;
if (C1 == 0)
                         //key 5 is pressed
 {
                                      //debounce
       delay();
       while (C1==0);
                                      //wait until release the key
       return 5;
}
if (C2 == 0)
                                               //key 6 is pressed
 {
                                             //debounce
   delay();
       while (C2==0);
                                     //wait until release the key
       return 6;
}
if (C3 == 0)
                                               //key 6 is pressed
{
                                      //debounce
       delay();
       while (C3==0);
                                       //wait until release the key
       return 7;
}
if (C4 == 0)
                                               //key 7 is pressed
 {
       delay();
                                        //debounce
       while (C4==0);
                                      //wait until release the key
       return 8;
}
//test row 3
```

```
R4=1;
R3=0;
R2=1;
R1=1;
if (C1 == 0)
                                             //key 8 is pressed
{
       delay();
                                      //debounce
       while (C1==0);
                                     //wait until release the key
       return 9;
}
if (C2 == 0)
                                             //key 9 is pressed
       delay();
                                     //debounce
       while (C2==0);
                                     //wait until release the key
  return 10;
}
if (C3 == 0)
                         //key A is pressed
{
                         //depounce
   delay();
       while (C3==0);
                                     //wait until release the key
       return 11;
}
if (C4 == 0)
                                              //key B is pressed
{
                                     //depounce
       delay();
       while (C4==0);
                                     //wait until release the key
       return 12;
}
//test row 4
R1=1:
R2=1;
R3=1;
R4=0;
if (C1 == 0)
                                             //key C is pressed
{
                                       //depounce
       delay();
       while (C1==0);
                                      //wait until release the key
       return 13;
}
if (C2 == 0)
                                             //key D is pressed
 ł
                                      //depounce
       delay();
                                     //wait until release the key
       while (C2==0);
       return 14;
```

```
- 39 -
```

```
}
 if (C3 == 0)
                                           //key E is pressed
  ł
        delay();
                                    //depounce
                                    //wait until release the key
        while (C3==0);
        return 15;
 }
 if (C4 == 0)
                        //key C is pressed
  {
                                    //depounce
        delay();
        while (C4==0);
                                    //wait until release the key
        return 16;
 }
 return 0;
                                           // Means no key has been pressed
}
void main (void)
{
  P1 = 0x0f;
 P3=0x00;
  LCD_init();
  LCD_row1();
  LCD_puts("< SERIAL KEYPAD >");
  LCD_row2();
  LCD_puts(" INTERFACING ");
  Delay(3);
 while(1)
  {
    key=READ_SWITCHES();
   if(key)
    {
       P3 = key-1;
       LCD_clear();
       LCD_row1();
       LCD_puts("< SERIAL KEYPAD >");
       LCD_row2();
       LCD_puts("KEY : ");
       switch(key)
       {
         case 1:
        {
                             LCD_putc('0');
                             break;
```

} case 2: { LCD_putc('1'); break; } case 3: { LCD_putc('2'); break; } case 4: { LCD_putc('3'); break; } case 5: { LCD_putc('4'); break; } case 6: { LCD_putc('5'); break; } case 7: { LCD_putc('6'); break; } case 8: { LCD_putc('7'); break; } case 9: { LCD_putc('8'); break;

	}	
case 10:	{	LCD_putc('9');
	}	break;
case 11:	{	LCD_putc('A');
	}	break;
case 12:	{	LCD_putc('B');
	}	break;
case 13:	{	LCD_putc('C');
	}	break;
case 14:	{	LCD_putc('D');
	}	Dreak;
case 15:	{	LCD_putc('E');
	}	oreak;
case 16:	{	}

```
LCD_putc('F');
break;
```

}// switch

}//if

}//while

}//main

```
void Delay(unsigned int duration)
{
    unsigned int r2;
        for (r2 = 0; r2<= duration;r2++)
    {
        LCD_delay(250);
        LCD_delay(250);
    }
}</pre>
```

Hardware configuration and realization:

- 1. Connect a 6 pin jumper or 6 pin bus from PORT 2 to LCD module available on board.
- 2. Connect 8 pin jumper to the hex keypad module on the board.
- 3. Turn ON and OFF or reset the board, to view the output.

Results/Output verification:

After programming the code into the microcontroller just reset the microcontroller. You can listen to the buzzer buzzing.


- 42 -

EXPERIMENT – 6(a)

Aim:

Write an Embedded C program for serial communication between Microcontroller to PC. Program to transmit message from microcontroller to PC serially using RS232.

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements:

- 1. Keil evaluation software
- 2. Flash Magic tool.
- 3. Terminal

Interfacing Serial communication between MCU to PC:



Basic Theory of 8051 Serial commutations:

UART (Universal Asynchronous Receiver and Transmitter)

One of the microcontroller features making it so powerful is an integrated UART, better known as a serial port. It is a full-duplex port, thus being able to transmit and receive data simultaneously and at different baud rates. Without it, serial data send and receive would be an enormously complicated part of the program in which the pin state is constantly changed and checked at regular intervals. When using UART, all the programmer has to do is to simply select serial port mode and baud rate. When it's done, serial data transmit is nothing but writing to the SBUF register, while data receive represents reading the same register. The microcontroller takes care of not making any error during data transmission.



Serial port must be configured prior to being used. In other words, it is necessary to determine how many bits is contained in one serial "word", baud rate and synchronization clock source. The whole process is in control of the bits of the SCON register (Serial Control).

	0	0	0	0	0	0	0	0	Value after reset
SCON	SM0	SM1	SM2	REN	TB8	RB8	TI	RI	Bit name
	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	

SM0 - Serial port mode bit 0 is used for serial port mode selection.

SM1 - Serial port mode bit 1.

SM2 - Serial port mode 2 bit, also known as multiprocessor communication enable bit.

TI - Transmit Interrupt flag is automatically set at the moment the last bit of one byte is sent. It's a signal to the processor that the line is available for a new byte transmit. It must be cleared from within the software.

RI - Receive Interrupt flag is automatically set upon one byte receive. It signals that byte is received and should be read quickly prior to being replaced by a new data. This bit is also cleared from within the software.

SM0	SM	1	Mode Description	Baud Rate
0	0	0	8-bit Shift Register	1/12 the quartz frequency
0	1	1	8-bit UART	Determined by the timer 1
1	0	2	9-bit UART	1/32 the quartz frequency (1/64
	the	quar	tz frequency)	
1	1	3	9-bit UART	Determined by the timer 1



Source code:

/*Program to transmit a message from Microcontroller to PC serially usingRS232.*/

```
#include <REG51.h> /* define 8051 registers */
void SendChar(unsigned char x);
void DisplayMesPC(unsigned char *);
void serial_init(void);
unsigned char *mes;
void main (void) /* main program start */
{
    serial_init();
    mes = "\r\nInstitute of Aeronautical engg\r\n\r\nWelcome to Serial
    communication Demo \r\n";
    DisplayMesPC(mes);
    mes = "\r\nif above txt visible, then transmission sucess\r\n";
```

```
DisplayMesPC(mes);
  while(1);
}
void SendChar(unsigned char x) // transmit function to send character to PC
{
 SBUF =x;
                            // wrting the character into the serial buffer
 TI = 0;
                            // Clearing the Transmit empty flag
while(!TI);
                            // wating for end of trasmission. after transmission
                     the TI flag will set.
}
void DisplayMesPC(unsigned char *mes)
{
 int counter;
 for (counter=0;mes[counter]!='\0';counter++)
 {
               SendChar(mes[counter]);
  }
}
void serial_init()
{
  TMOD = 0x20;
                           /* GATE OFF,C/#T = 0, M1 M0 = 10(8 BIT AUTO
RELOAD) TIMER 0, TIMER 1 IN MODE 2(AUTO RELOAD MODE)*/
 SCON = 0x50;
                            /* SERIAL PORT IN MODE2 8-BIT UART VARIABLE
                     BAUDRATE */
                            /* TIMER 1 FOR BAUD RATE GEN(9.6K)*/
  TH1 = 0xfd;
  TR1 = 1;
                            /* baud rate timer start*/
}
```

Flow chart:



Results/Output verification:

Now the program is running on Microcontroller. And the output can be seen in the board. You can see terminal device .

EXPERIMENT – 6(b)

Aim:

Write an Embedded C program for serial communication between Microcontroller to PC. Program to receive a message from PC to microcontroller serially using RS232.

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements:

- 1. Keil evaluation software
- 2. Flash Magic tool.
- 3. Terminal

Interfacing Serial communication between MCU to PC:



Basic Theory of 8051 Serial commutations:

UART (Universal Asynchronous Receiver and Transmitter)

One of the microcontroller features making it so powerful is an integrated UART, better known as a serial port.

It is a full-duplex port, thus being able to transmit and receive data simultaneously and at different baud rates. Without it, serial data send and receive would be an enormously complicated part of the program in which the pin state is constantly changed and checked at regular intervals. When using UART, all the programmer has to do is to simply select serial port mode and baud rate. When it's done, serial data transmit is nothing but writing to the SBUF register, while data receive represents reading the same register. The microcontroller takes care

of not making any error during data transmission.



Serial port must be configured prior to being used. In other words, it is necessary to determine how many bits is contained in one serial "word", baud rate and synchronization clock source. The whole process is in control of the bits of the SCON register (Serial Control).

	0	0	0	0	0	0	0	0	Value after reset
SCON	SMO	SM1	SM2	REN	TB8	RB8	TI	RI	Bit name
No de contra servicio de la contra de la con	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0	-

SM0 - Serial port mode bit 0 is used for serial port mode selection.

SM1 - Serial port mode bit 1.

SM2 - Serial port mode 2 bit, also known as multiprocessor communication enable bit.

TI - Transmit Interrupt flag is automatically set at the moment the last bit of one byte is sent. It's a signal

to the processor that the line is available for a new byte transmit. It must be cleared from within the software.

RI - Receive Interrupt flag is automatically set upon one byte receive. It signals that byte is received and

should be read quickly prior to being replaced by a new data. This bit is also cleared from within the software.

SM0	SM	1	Mode Description	Baud Rate
0	0	0	8-bit Shift Register	1/12 the quartz frequency



Source code:

→______

/*Program to receive a message from PC to microcontroller serially usingRS232.*/

SBUF

```
#include <reg51.h>
```

```
unsigned char ReceiveSerial() {
```

unsigned char c;

```
/* configure timer for the correct baud rate*/ TH1 = 0xe6; /*
TMOD = 0x20;
1200 bps for 12 MHz clock */
TCON = 0x00; /* Set timer to not running */
```

```
SCON = 0x50; /* Set Serial IO to receive and normal mode */ TR1 = 1;
                                                                           /*
start timer to Receive */
while ((SCON & 0x01) == 0) /* wait for receive data */;
c = SBUF;
return c;
```

```
void main(void) {
```

}

unsigned char c;

```
while(1)
char ReceivSerial()
 ļ
    }
```

Flow chart:



Results/Output verification:

Now the program is running on Microcontroller. And the output can be seen in the board.

EXPERIMENT – 7

Program to interface Stepper Motor to rotate the motor in clockwise and anticlockwise directions

Aim:

Write a Embedded C Program to interface Stepper Motor to rotate the motor in clockwise and anticlockwise directions

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.
- 6.Stepper motor

Software Requirements:

- 1. Keil evaluation software
- 2. Flash Magic tool.

Stepper Motor Interfacing with 8051:



Interfacing of stepper motor with 8051

P0.3	P0.2	P0.1	P0.0	Clock Wise	Anti Clockwise	HEX value
0	0	0	1	1	4	01
0	0	1	0	2	3	02
0	1	0	0	. 3	2	04
1	0	0	0	4	1	08

Switching sequence : One Phase excitation (Wave drive)

Switching sequence: Two phase excitation (High torque excitation)

P0.3	P0.2	P0.1	P0.0	Clock Wise	Anti Clockwise	HEX value
0	0	1	1	1	4	03
0	1	1	0	2	3	06
1	1	0	0	3	2	OC
1	0	0	1	4	1	09

Source code:

/*Program to interface Stepper Motor to rotate the motor in clockwise and anticlockwise directions*/

#include <reg51.h>

sbit SW1 = P1^0; sbit SW2 = P1^1;

void motor_delay(int sec) ;

void main(void)

```
{
```

```
P3=0x00;
```

```
SW1 = 0;
```

```
SW2 = 0;
```

while(1)

{

```
if(SW1 == 0)
    {
       P3 = 0x50;
       motor_delay(2);
       P3 = 0x90;
       motor_delay(2);
       P3 = 0xA0;
       motor_delay(2);
       P3 = 0x60;
       motor_delay(2);
     }
    else if(SW2 == 0)
     {
       P3 = 0x60;
       motor_delay(2);
       P3 = 0xA0;
       motor_delay(2);
       P3 = 0x90;
       motor_delay(2);
       P3 = 0x50;
       motor_delay(2);
     }
  }
void motor_delay(int sec)
 int i,j,secd;
  for (secd=0;secd<=sec;secd++)</pre>
    for(i=0;i<=4;i++)
           for (j=0;j<=800;j++)
```

}

{

Result:

}

- 1. Connector the jumpers at the stepper motor driver IC.
- 2. Connect the switch pins to the port pins selected.
- 3. Connect the Stepper motor to the available pins beside the serial port.



{ }



<u>EXPERIMENT – 8</u>

Develop necessary interfacing circuit to read data from i) temperature sensor and process using 89c51 sdk, the data has to display terminal window

Aim:

Write a program to read data from temperature sensor and display the temperature value.

Equipment Requirements:

Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements:

- 1. Keil evaluation software
- 2. Flash Magic tool.
- 3. Terminal device

Temperature Sensor Interfacing with 8051:



Source code:

/*Program to get analog input from Temperature sensor and display the temperature value on PC Monitor.*/

#include <reg51.h> /* define 8051 registers */
#include "lcd.h"

sbit rd=P1^0;	//Read signal P1.0
sbit wr=P1^1;	//Write signal P1.1
sbit intr=P1^2;	//INTR signal P1.3

void conv(); //Start of conversion function void read(); //Read ADC function void display(); void Delay(int a); void SendChar(unsigned char x); void DisplayMesPC(unsigned char *);

unsigned char *mes; unsigned char adc_val; unsigned int value,temp,temp1,temp2,temp3;

void Delay(int a)

```
{
  char i;
  for(i=0;i<a;i++)
  {
    LCD_delay(250);
    LCD_delay(250);
  }
}
void serial_init()
ł
      = 0x20;
                   /* GATE OFF,C/\#T = 0, M1 M0 = 10(8 BIT AUTO RELOAD)
TIMER 0, TIMER 1 IN 2(AUTO RELOAD MODE)*/
SCON = 0x50; /* SERIAL PORT IN MODE2 8-BIT UART VARIABLE
              BAUDRATE*/
  TH1 = 0xfd;
                     /* TIMER 1 FOR BAUD RATE GEN(9.6K)*/
  TR1 = 1;
                    /* baud rate timer start*/
}
void PowerOn()
{
  unsigned char inner, outer;
  for (outer = 0x00; outer < 0x10; outer++)
  ł
    for (inner = 0x00; inner < 0xFF; inner++);
  }
  LCD_init();
  for (inner = 0; inner < 10; inner++)
        LCD_delay(2);
              serial_init();
}
void main()
  P0=0xFF;
  P1=0x04;
  PowerOn();
  while(1)
  {
```

```
LCD_clear();
    LCD_row1();
    LCD_puts("Temperature sensor ");
    DisplayMesPC("\r\nTemparature Value : ");
    conv();
                                                   //Start conversion
    read();
                                                   //Read ADC
    display();
                                           //Send the read value PC and LCD
    Delay(4);
   J
}
void conv()
ł
  wr = 0;
                      //Make WR low
  wr = 1;
                     //Make WR high
  while(intr);
                      //Wait for INTR to go low
}
void read()
{
                     //Make RD low
  rd = 0;
  adc_val = P0;
                        //Read ADC port
                     //Make RD high
  rd = 1;
}
void display()
                        // display the adc vvalue in the form of milli volts
ł
    LCD_row2();
   LCD_puts(" Temp :");
       value=adc_val;
 value=value*196;
                      //since resolution is 5V/255=19.6mv
 value=value/100;
                       // 10 division by 196 instead 19.6 another 10 is 1^*
                             corresponds 10mv
 if(value>=1000)
       {
        temp=value/1000;
        adc_val=temp+48;
        LCD_putc(adc_val);
        SendChar(adc_val);
 }
        temp1=value%1000;
        if(temp1>=100&&temp1<=999){
        temp=temp1;
```

```
- 59 -
```

```
temp=temp/100;
        adc_val=temp+48;
        LCD_putc(adc_val);
        SendChar(adc_val);
}
        Else
       {
               LCD_putc('0');
               SendChar('0');
        }
               temp2=temp1%100;
               if(temp2>=10&&temp2<=99)
       {
               temp=temp2;
               temp=temp/10;
               adc_val=temp+48;
               LCD_putc(adc_val);
               SendChar(adc_val);
        }
               else
       {
                   LCD_putc('0');
                   SendChar('0');
               }
               temp3=temp2%10;
               if(temp3>0&&temp3<10){
               temp=temp3;
               adc_val=temp+48;
               LCD_putc(adc_val);
               SendChar(adc_val);
               }
                      else {
                      LCD_putc('0');
                      SendChar('0');
                      }
 LCD_putc(0XDF);
 SendChar('*');
 SendChar(' ');
 SendChar('C');
 LCD_putc('*');
 LCD_putc('C');
}
void SendChar(unsigned char x)
                                    // transmit function to send character to PC
```

```
- 60 -
```

```
{
   SBUF =x; // wrting the character into the serial buffer
   TI = 0; // Clearing the Transmit empty flag
   while(!TI); // wating for end of trasmission. after transmission the TI flag will set.
}
void DisplayMesPC(unsigned char *mes)
{
   int counter;
   for(counter=0;mes[counter]!='\0';counter++)
   {
      SendChar(mes[counter]);
   }
}
```

Hardware configuration:

To test the board Power supply cable should be connected to the Board and serial cable must be connected to

the computer. The Data line of the ADC is connected to the P0 of microcontroller. The RD, WR, INTR (J32)

signals are connected to the P1.0, P1.1, P1.2 respectively. The Jumper should be connected at J22. To Connect

Temperature sensor to ADC input Connect J22 1&2 (Temp sensor) with jumper The temperature is displayed in LCD and same thing displayed on the PC.



RESULTS:

To check the output connect the hardware as shown above diagram, increase the temperature on the sensor side then we will see the variation on sensor data on both HyperTerminal and lcd.

SUBJECT SUBJECT
Ball Correction and Co
COTA CATE
(00)
CONTRACTOR AND

EXPERIMENT –9

Write a Program to

Port RTOS on to 89V51 Microcontroller and verify. Run 2 to 3 tasks simultaneously on 89V51 SDK. Use LCD interface, LED interface, Serial communication. **Aim:**

Write an Embedded C program to sort RTOS on to 89V51 Microcontroller and verify. Run 2 to 3 tasks simultaneously on P89V51RD2.Use LCD interface, LED interface, Serial communication.

Equipment Requirements: Hardware Requirements:

- 1. 89V51RD2 Development board
- 2. A serial 9 pin cable wired one to one from female connector to male connector
- 3. PC with serial port
- 4. 9V adaptor
- 5. Connecting jumper and Connecting Wires.

Software Requirements:

1. Keil evaluation software

2. Flash Magic tool.

RTOS Introduction: What is a real-time System?

Timeliness is the single most important aspect of a real -time system. These systems respond to a series of external inputs, which arrive in an unpredictable fashion. The real-time systems process these inputs, take appropriate decisions and also generate output necessary to control the peripherals connected to them. As defined by Donald Gillies "A real-time system is one in which the correctness of the computations not only depends upon the logical correctness of the computation but also upon the time in which the result is produced. If the timing constraints are not met, system failure is said to have occurred."

It is essential that the timing constraints of the system are guaranteed to be met. Guaranteeing timing behavior requires that the system be predictable. The design of a real -time system must specify the timing requirements of the system and ensure that the system performance is both correct and timely. There are three types of time constraints:

Hard: A late response is incorrect and implies a system failure. An example of such a system is of medical equipment monitoring vital functions of a human body, where a late response would be considered as a failure.

Soft: Timeliness requirements are defined by using an average response e time. If a single computation is late, it is not usually significant, although repeated late computation can result in system failures. An example of such a system includes airlines reservation systems.

Firm: This is a combination of both hard and soft timeliness requirements. The computation has a shorter soft requirement and a longer hard requirement. For example, a patient ventilator must mechanically ventilate the patient a certain amount in a given time period. A few seconds' delay in the initiation of breath is allowed, but not more than that.

Experimental procedure:

Open the keil IDE and do the same procedure like create new project and build the application. Then open Flash magic and download the hex file. Please refer the above experimental procedure for keil4 IDE. In this RTOS experiment we have to do few more settings for creating new project (if you want to create new project then only do these settings),just follow the settings as below mentioned.

After creating new project file go to target and do these settings: SELECT TARGET and right click on target settings and select RAM size is 0X0000 to 0X1000.Again go to settings and select C51 and select LEVEL 9. And do the below

Source code:

/*Port RTOS on to 89V51 Microcontroller and verify.

- Run 2 to 3 tasks simultaneously on 89V51 SDK.
- Use LCD interface, LED interface, Serial communication. */

#include "rtos.h"
#include"uart.h"
#include"lcd.h"

unsigned char task_time_counter1=0,task_time_counter2,task_time_counter3=0; struct generic_sync xdata mut;

sbit	LED1 =	P0^0;
sbit	LED2 =	P0^1;
sbit	LED3 =	P0^2;

```
void PowerOn()
```

{

unsigned char inner, outer;

```
for (outer = 0x00; outer < 0x10; outer++)
{
    for (inner = 0x00; inner < 0xFF; inner++);</pre>
```

```
}
```

```
LCD_init();
for (inner = 0; inner < 10; inner++)
LCD_delay(2);
```

```
serial_init();
```

```
}
```

```
void LED_TASK()
{
 while(1) {
        k_acquire(&mut);
        k_yield();
        if(task_time_counter1==20){
        task_time_counter1=0;
        LED1=LED1 ^ 1;
  DisplayMesPC("\r\nLED Task Running");
        task_time_counter1++;
        k_release(&mut);
        k_yield();
 }
}
void LCD_TASK() {
unsigned char counter=0;
 LCD_clear();
 LCD_row1(); LCD_puts("LCD Task Running");
 LCD_row2();
 while(1) {
        k_acquire(&mut);
        k_yield();
               if(task_time_counter2==5){
         LCD_putc(counter+48);
          counter++;
                     LED3=LED3 ^ 1;
          task_time_counter2=0;
                DisplayMesPC("\r\nLCD Task Running");
                                          if(counter>15){
                            counter=0;
                               LCD_row2();
                               LCD_puts("
                                                   ");
                                   LCD_row2();
                              }
         }
        task_time_counter2++;
        k_release(&mut);
        k_yield();
 }
```

```
- 64 -
```

}

```
void UART_TASK() {
 while(1) {
        k_acquire(&mut);
        k_yield();
        if(task_time_counter3==10){
        task_time_counter3=0;
        LED2=LED2 ^{1};
  DisplayMesPC("\r\nUART Task Running");
        task_time_counter3++;
        k_release(&mut);
        k_yield();
 }
}
void main()
{
 P0=0x00;
 PowerOn();
 DisplayMesPC("\r\nRTOS For 8051 Microcontroller");
 k_create_mutex(&mut);
 k_task_create(LED_TASK, "a", 1);
 k_task_create(LCD_TASK, "b", 1);
 k_task_create(UART_TASK, "c", 1);
 k_start();
```

}

Hardware configuration:



To test the board

Power supply cable should be connected to the M7 Board and serial cable must be connected to the computer.

Jumpers should be connected to J39[LED's],JP3 and J6[LCD]. To check the output just reset the board and give proper connections and check the output on LCD, LED and on hyperterminal. H ere we are assigned three leds for 3 tasks one led for led,second one for lcd and third one for UART. There you can observe the the task time on each and every led.





Result

You can find on LCD display data and led blinks and UART data displayed this terminal like this.

🧟 Terminal v1.9b - 201112308 - by Brzy++	
Denset COM Pot Bad rate Data bite Perity Step bits Handhabing Reficent COM1 Com0 14400 57500 C 6 nonce LHbp CoM4 Cable Perity Step bits Handhabing Lbbp CoM4 Cable Perity Step bits Handhabing Lbbp Cable Cable Feity Step bits Handhabing Lbbp Cable Feity Step bits Feity Step bits Handhabing Lbbp Cable Cable Feity Step bits Handhabing Feity Lbbp Cable Cable Feity Step bits Handhabing Feity Step bits Handhabing Lbbp Cable Cable Feity Step bits Handhabing Feity	
Setting: Settors: AutoStat Script CR=LF Steam log custom BR RxClear ASCII table Scripting AutoStat Script CR=LF Stay on Top 133828 27 Graph Remote	CTS CD DSR RI
Receive Receive Re	
LED Task Running LCD Task Running	
Tenna CLEAN SendFie 1 + CR-CR-LF BREAK	
Macros CMD CMD2 CMD3 CMD4 CMD5 CMD5 CMD7 M8 M9 M10 M11 M12 M13 M14 M15 M16 M17 M18 M19 M20 M21 M22 M23 M24	
a]	□ +CR→ Send
Disconnected Rix 10296 (Tx 318 Rix 0K	
🖅 Start 🕘 elton 🕼 ES Lab E 🔆 Rash Ma 🔮 Tommal 😂 Experim 😢 C.\Docu 🛸 Veri.z 🚔 Real tim 💐 EddPlus 🧶 21% of 🌾 🛛	0 10 10 10 PM

EXPERIMENT-10

Analog to Digital Converter unit (ADC 0809)

AIM: Write a program to develop analog to digital converter using 89C51 board.

```
Program Code : Digital to analog (DAC)
#include<8051.h>
#define HIGH 01;
#define LOW 00;
 xdata at 0xffc5 unsigned char swt;
idata unsigned char dat;
 _idata unsigned char i;
  bit at(0x94) SCLK;
  bit at(0x95) SDA;
bit ACK;
void I2C_Start(void);
void I2C_Stop(void);
void I2C_Write(unsigned char j);
unsigned char I2C_Read(void);
void Delay Time();
void I2C_Start(void)
                             //Start I2C by creating clock by setting and clearing the port pins
{
  SCLK=LOW;
  SDA=LOW;
  Delay_Time();
  SCLK = HIGH;
  Delay_Time();
  SDA=HIGH;
  Delay_Time();
  SDA = LOW:
  Delay_Time();
  SCLK = LOW;
}
void I2C_Stop(void)
                             //Stop I2C operation by clearing the SCLK Pin
  SCLK = LOW:
  Delay_Time();
  SDA = HIGH;
}
void I2C_Write(unsigned char j) // shifting data bit by bit to MSB and moving through i2c
{
 dat=j;
 for(i=0;i<8;i++)
```

{

```
SDA = dat \& 0x80;
    dat=dat<<1;
    SCLK = HIGH;
    Delay_Time();
    SCLK = LOW;
   }
 SDA=HIGH;
 Delay_Time();
 SCLK = HIGH;
 Delay_Time();
 ACK = SDA;
 Delay_Time();
 SCLK = LOW;
}
unsigned char I2C_Read(void) //reading from i2c device bit by bit
{
 unsigned char i,j;
 j = 0;
 i = SDA;
 for(i=0;i<8;i++)
  {
   j<<=1;
   SCLK = HIGH;
   i \models SDA;
   Delay_Time();
   SCLK = LOW;
 }
 Delay_Time();
 SDA = LOW;
 Delay_Time();
 SCLK = HIGH;
 Delay_Time();
 SCLK = LOW;
 Delay_Time();
 SDA = HIGH;
 return j;
}
void main()
ł
 unsigned int i=0x00;
        I2C_Start();
        I2C_Write(0x9E); //send device address
        I2C_Write(0x40);
                             //send device's control register address
        I2C_Start();
        I2C_Write(0x9E); // send command for read
        while(1)
   {
```

```
- 72 -
```

```
if((swt & 0x1f)== 0x1E)
    {
        i=i+0x0a;
        if(i>0xff)
        i=0x00;
        I2C_Write(i);
        Delay_Time();
        }
    }
    void Delay_Time()
    {
        unsigned int i;
        for(i=0;i<=5000;i++);
    }
</pre>
```

```
ADC 0809 is an 8-channel 10
```

Digital form. In ADC section a jumper is provided to select either external analog input from signal conditioning as input source or can select internal 5V generator, which is variable from 0-5V. Th

the any of the port by using the Bus/connector. Reference voltage of 2.5V is given at the reference input so that the analog input span is 5V. In a sample program provided with the module the digital ou

Microcontroller, can be view on the hyper terminal of the PC

Features of ADC0809:

- \square \square Resolution: 8 Bits.
- □ □ Operates ratio metrically or with 5VDC, 2.5VDC, or analog span adjusted
- \Box voltage reference.
- \Box \Box Differential analog voltage inputs
- \square \square Works with 2.5V voltage reference.
- $\Box \Box$ On-chip clock generator.
- $\Box \Box OV$ to 5V analog input voltage range with single 5V supply.
- $\Box \Box$ No zero adjusts required.

EXPERIMENT-11

Aim:

Program to interface DAC device with P89V51RD2 and observer the analog output in CRO.

Hardware and Software Requirement:

- **1.** Set port 1 as output port.
- 2. Initialize port 1 as 00
- 3. Go on incrementing value till max value is reached at port1, for the upward going part of the triangular wave.
- 4. For 1kHz triangular wave, increase the value by 5 each time.
- 5. Once max value is reached, decrease the value in same steps till min value is reached.
- 6. Repeat in infinite loop.



Hardware Connection



Actual Connection

```
Code
#include<reg51.h>
                                    //Header file for 8051 void main()
                                                                          // Start of main() function
{
P1 = 0x00;
                                    // Initialize Port 1 as Output
while(1)
                                     // Infinite Loop
{
       // 1st do-while for upward portion of //triangular wave
do
{
                                    // Increment P1 to get upward portion
P1 += 0x05;
}
                                     // stop loop after reaching max value do
while(P1<0xFF);
                                                                                  // 2nd do-while for
downward portion of //triangular wave
{
P1 = 0x05;
                             // Decrement P1to get downward portion
}
                                    // stop loop after reaching lowest value
while(P1>0x00);
}
}
```

Expected Output



EXPERIMENT-12

Program to interface Elevator.

Aim: Write a Program to interface a Elevator

Program :

#include<reg51.h>

void main(void)

{

unsigned char F[10]={0,1,2,3,4,5,6,7,8,9};

unsigned char req,cur,i,j;

P0=0x09; cur=P0; while(1) { P1=0x02; req=P1; if(cur==req) { P0=F[req]; } else if(req>cur) { for(i=cur;i<=req;i++) { P0=F[i]; for(j=0;j<250;j++);

}

```
}
else
{
for(i=cur;i>=req;i--)
{ P0=F[i];
for(j=0;j<250;j++);
}
} cur=req; P0=F[cur];
}</pre>
```

```
Interfacing Model:
```



Result: Elevator is interfaced with 8051 microcontroller.



TEXT BOOKS:

- 1) Computers and Components, Wayne Wolf, Elseveir.
- 2) The 8051 Microcontroller, Third Edition, Kenneth J. Ayala, Thomson .
- 3) Embedded systems, lyla B das

REFERENCES:

- 2) Embedding system building blocks, Labrosse, via CMP publishers.
- 3) Embedded Systems, Raj Kamal, TMH.
- 4) Micro Controllers, Ajay V Deshmukhi, TMH.
- 5) Embedded System Design, Frank Vahid, Tony Givargis, John Wiley.
- 6) Microcontrollers, Raj Kamal, Pearson Edition.
- 7) An Embedded Software Primer, David E. Simon, Pearson Edition.
- 8) 'Embedded/Real-Time Systems', KVKKF Prasad, Dreamtech, Press

Web References:

- 1. https://www.cadsoftusa.com/download-eagle/freeware/
- 2. http://www.dauniv.ac.in/downloads/EmbsysRevEd_PPTs/Chap01Lesson_1Emsys.pdf
- 3. http://en.wikipedia.org/wiki/Embedded_system
- 4. http://www.atmel.in/Images/MCU_vs_MPU_Article.pdf
- 5. http://maxembedded.com/2011/06/05/mcu-vs-mpu/
- 6. http://www.cadsoft.de/wp-content/uploads/2011/05/V6_tutorial_en.pdf 6.
- 7. http://www.mikrocontroller.net/attachment/17909/Protel_99_SE_Traning_Manual_P CB_ Desi gn.pdf